

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

Oil Cons.
N.M. DIV-Dist. 2
1301 W. Grand Avenue
Artesia, NM 88210
FORM APPROVED
Bureau of Land Management 1004-0135
March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1 Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2 Name of Operator

Mack Energy Corporation

3 Address and Telephone No

P.O. Box 960, Artesia, NM 88211-0960

4 Location of Well (Footage, Sec., T. R., M. or Survey Description)

1100 FNL & 660 FEL, Sec. 14 T17S R31E, A

5 Lease Designation and Serial No

NM-98120

6 If Indian, Allottee or Tribe Name

7 If Unit or CA, Agreement Designation

8 Well Name and No

Skelly Unit #905

9 API Well No

30-015-31371

10 Field and Pool, or Exploratory Area

Fren Paddock East

11 County or Parish, State

Eddy, NM

12 CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13 Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directly drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Mack Energy Corporation proposes to plug and abandon well as follows:

1. Notify BLM 24 hours before starting plugging operations.
2. Set CIBP @ 5188' w/35' cement cap, circulate hole w/mud.
3. Set 100' cement plug from 4250-4150' 50' above and below 8 5/8 casing set @ 4200, WOC and tag.
4. Set 100' cement plug from 800-700' 50' above and below 11 3/4 casing set @ 750', WOC and tag.
5. Set 60' surface plug.
6. Install dry hole marker.

**APPROVAL SUBJECT TO
GENERAL REQUIREMENTS AND
SPECIAL STIPULATIONS ATTACHED**

14. I hereby certify that the foregoing is true and correct

Signed

Alexis C. Swoboda

Title

Production Analyst

Date

8/26/02

(This space for Federal or State office use)

Approved by

(ORIG. SGD.) ALEXIS C. SWOBODA

Title

PETROLEUM ENGINEER


Date

AUG 30 2002

Conditions of approval, if any:

**Mack Energy Corporation
Skelly Unit #905**

Before



11 3/4 @ 750'


8 5/8 @ 4200'

CIBP @ 5600'

CIBP @ 10600'

**5 1/2 casing set
@ 12387'**

After



60' surface plug

11 3/4 @ 750'

**Cement plug
from 800-700'**

**Cement plug
from 4250-4150'**

8 5/8 @ 4200'

CIBP @ 5188'

CIBP @ 5600'

CIBP @ 10600'

**5 1/2 casing set
@ 12387'**