

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

RECEIVED

Form C-103
Revised 10-1-77

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	<input checked="" type="checkbox"/>
FILE	<input checked="" type="checkbox"/>
U.S.O.S.	<input type="checkbox"/>
LAND OFFICE	<input checked="" type="checkbox"/>
OPERATOR	<input checked="" type="checkbox"/>

MAR 14 '88

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. 2029	

O. C. L.
ARTESIA, OFFICE

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name Empire Abo Unit
2. Name of Operator ARCO OIL & GAS COMPANY Division of Atlantic Richfield Company	8. Farm or Lease Name Empire Abo Unit "Q"
3. Address of Operator P.O. Box 1710 Hobbs, New Mexico 88240	9. Well No. 5
4. Location of Well UNIT LETTER D 660 FEET FROM THE North LINE AND 990 FEET FROM THE West LINE, SECTION 16 TOWNSHIP 18S RANGE 27E NMPM.	10. Field and Pool, or Wildcat Empire Abo
15. Elevation (Show whether DF, RT, GR, etc.) 3484 GR	12. County Eddy

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input checked="" type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPER. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Test anchors and reset where pattern is not acceptable
2. MIRU DDP - pump approx 75-100 bbls prod. H2O down tbg
3. Install BOP, POH w/all, T.O.H.
4. GIH w/drillable CIBP to 5570'
5. Set CIBP @ 5570'
6. Unlatch from CIBP & POH w/1 jt, pump approx 150 bbl. 8.6# brine w/2 gal WT 675 per 10 bbl brine, until circulation is established
7. Shut in csg valve & pressure up on csg to 500# for 15 min
8. If csg holds, POH w/tbg laying down. Leave 1 jt hanging on tbg bonnet - SI csg & tbg valve. Strip wellhead of excess connection. Remove BOP & RDCL
9. If test fails, POH & pick up pkr & GIH to 1000' and test csg - continue setting and unsetting pkr until approximate footage of hole is found.
(a) get with engr. dept. for evaluation of well

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED James G. Burns TITLE Services Supv. DATE 3-11,88

APPROVED BY Mike Williams TITLE Oil & Gas Inspector DATE MAR 14 1988

CONDITIONS OF APPROVAL, IF ANY: