

RECEIVED

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

NEW MEXICO OIL CONSERVATION COMMISSION

SEP 27 1982

O. C. D.
ARTESIA, OFFICE

| | | |
|------------------------|---|---|
| NO. OF COPIES RECEIVED | | |
| DISTRIBUTION | | |
| SANTA FE | 1 | |
| FILE | 1 | 1 |
| U.S.G.S. | | |
| LAND OFFICE | | |
| OPERATOR | 1 | |

5a. Indicate Type of Lease
State Fee

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL GAS WELL OTHER - Water Injection Well

Name of Operator: Boyd Operating Company

Address of Operator: P. O. Box 1756, Roswell, N. M. 88201

Location of Well:
UNIT LETTER B FEET FROM THE 330 LINE AND 2310 FEET FROM
THE E LINE, SECTION 14 TOWNSHIP 18S RANGE 28E NMPM.

7. Unit Agreement Name

8. Farm or Lease Name
State C

9. Well No.
#5

10. Field and Pool, or Wildcat
Artesia Qn Gb SA

12. County
Eddy

15. Elevation (Show whether DF, RT, GR, etc.)
3600'

6. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

| | | | |
|--|--|---|---|
| NOTICE OF INTENTION TO: | | SUBSEQUENT REPORT OF: | |
| PERFORM REMEDIAL WORK <input type="checkbox"/> | PLUG AND ABANDON <input checked="" type="checkbox"/> | REMEDIAL WORK <input type="checkbox"/> | ALTERING CASING <input type="checkbox"/> |
| TEMPORARILY ABANDON <input type="checkbox"/> | CHANGE PLANS <input type="checkbox"/> | COMMENCE DRILLING OPNS. <input type="checkbox"/> | PLUG AND ABANDONMENT <input type="checkbox"/> |
| PULL OR ALTER CASING <input type="checkbox"/> | OTHER <input type="checkbox"/> | CASING TEST AND CEMENT JOB <input type="checkbox"/> | OTHER <input type="checkbox"/> |

7. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

8 5/8" @ 327' W/100 sks.; 7" @ 2424 w/150 sx.
Tubing from 2192' to 2248'. 7" packer @ 2248-51'. 10 jts tubing below.

- 1) Pull tubing & packer @ 2093'.
- 2) Set packer or retainer and squeeze open hole from 2424' to 2585'.
- 3) Test annulus above 2090'.
- 4) Spot cement plug @ 662'-base of salt.
- 5) Spot cement plug @ 445'-top of salt.
- 6) 10 sx plug at surface & marker.
- 7) Clean up location.
- * 8) Squeeze down braden head w/35 sy

16. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Operator DATE 9/24/82

APPROVED BY [Signature] TITLE OIL AND GAS INSPECTOR DATE OCT - 4 1982

CONDITIONS OF APPROVAL, IF ANY:
* As Noted Above

Plugging