

RECEIVED

JAN 4 1973

NEW MEXICO OIL CONSERVATION COMMISSION

O. C. C.
ARTESIA, OFFICE

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	/
FILE	/
U.S.G.S.	
LAND OFFICE	
OPERATOR	/

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. E-1287

<p align="center">SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</p>		
1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name	
2. Name of Operator KERSEY & COMPANY ✓	8. Farm or Lease Name Sheldon	
3. Address of Operator P. O. Box 316, Artesia, New Mexico 88210	9. Well No. 1	
4. Location of Well UNIT LETTER 0 6600 FEET FROM THE South LINE AND 1980 FEET FROM THE East LINE, SECTION 14 TOWNSHIP 18S RANGE 28E NMPM.	10. Field and Pool, or Wildcat Artesia Queen Grayburg SA	
15. Elevation (Show whether DF, RT, GR, etc.)	12. County Eddy	

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set Halliburton Bridging Plug at 2300' with 5 sack cement plug on it.
2. Mudded hole back to 1575' and shot 5 1/2" casing off.
3. Set 100' Cement Plug In and out of 5 1/2" casing where shot off.
4. Mudded hole back to bottom of 8 5/8" casing. Set 25 sack cement plug in and out of this casing.
5. Shot off 8 5/8" casing at 80'. Set 25 sack plug in and out of this casing.
6. Mudded hole to surface and set marker in cement.

*Casing left in hole 8 5/8" from 80 - 444
5 1/2" " 1575 - 2450*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Harold Kersey</u>	TITLE <u>Owner</u>	DATE <u>January 3, 1973</u>
APPROVED BY <u>[Signature]</u>	TITLE <u>OIL AND GAS INSPECTOR</u>	DATE <u>JUN 1 1974</u>
CONDITIONS OF APPROVAL, IF ANY:		