

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

DEC 21 1993

WELL API NO.
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. E-1392
7. Lease Name or Unit Agreement Name State G
8. Well No. 2
9. Pool name or Wildcat Artesia-Qn-GRB-SA
10. Elevation (Show whether DF, RKB, RT, GR, etc.)

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
OIL WELL GAS WELL OTHER

2. Name of Operator
Yates Drilling Company

3. Address of Operator
105 South 4th Street, Artesia, NM 88210

4. Well Location
Unit Letter C : 330 Feet From The North Line and 1650 Feet From The West Line
Section 22 Township 18S Range 28E NMPM Eddy County

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Set CIBP @ 2400' in 7" casing.
- Dump 125 sacks of cement on CIBP.
- Spot 50 sacks plug @ ~~1500'~~ and tag top. 1800
- Spot 50 sacks plug @ 1050' and tag top.
- Spot 50 sacks plug @ 610' and tag top.
- Pump 175 sacks of cement down 8 5/8" casing, squeezing approx. 90 sacks out perfs. @ 250-300', leaving 8 5/8" full of cement. - circ cement to surface
- Set surface marker.

NOTE: Hole will be filled with mud between plugs.

Notify N.M.D.C.C. in a letter dated _____

Plugging

I hereby certify that the information above is true and complete to the best of my knowledge and belief.


SIGNATURE Toby Rhoden TITLE Petroleum Engineer DATE 12-20-93

TYPE OR PRINT NAME _____ TELEPHONE NO. _____

(This space for State Use)

APPROVED BY [Signature] TITLE [Signature] DATE 1/20/94

CONDITIONS OF APPROVAL, IF ANY:



300 Estimated TOC

0 to 560 8-5/8", 24#, Cemented w/50 sacks in 10-1/4" Hole

560 to 2,000 Open Hole (8")

2,000 to 2,450 7" Casing Cemented w/30 sacks in 8" Hole

2,450 to 2,558 Open Hole