

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	/
FILE	/
U.S.G.S.	
LAND OFFICE	
OPERATOR	/

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. 647
7. Unit Agreement Name
8. Farm or Lease Name Basler Yates State
9. Well No. 17
10. Field and Pool, or Wildcat Artesia
12. County Eddy

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator American Petrofina Company of Texas
3. Address of Operator Box 1311, Big Spring, Texas 79720
4. Location of Well UNIT LETTER B , 2400 FEET FROM THE East LINE AND 805 FEET FROM THE North LINE, SECTION 28 TOWNSHIP 18N RANGE 28E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3550 DF

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	
		OTHER <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Pump 50 sack cement plug to bottom through 2" EUE tubing using 10# mud as displacement fluid. Fill up 50'.
 2. Pull 1500' 5 1/2" casing.
 3. Fill hole with 10# mud.
 4. Spot 25 sack cement plug at 1000'.
 5. Spot 25 sack cement plug at 290' (Bottom of 10 3/4" casing).
 6. Put 5 sack cement plug and 4" pipe marker in top of 10 3/4" casing. Fill up 9'.
- This work will be commenced on or about January 25, 1968.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J. M. Denson TITLE Asst. Dist. Mgr. of Production DATE December 21, 1967

APPROVED BY W. A. Gressett TITLE Asst. Dist. Mgr. of Production DATE 12/21/67
CONDITIONS OF APPROVAL, IF ANY: spot a 25 sack plug at stub of 5 1/2" casing