

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

RECEIVED
NEW MEXICO OIL CONSERVATION COMMISSION

AUG 24 1970

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

O. G. S.
ARTESIA, OFFICE

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. 647

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input checked="" type="checkbox"/> Water Injection Well	7. Unit Agreement Name
2. Name of Operator AMERICAN PETROFINA COMPANY OF TEXAS	8. Farm or Lease Name Welch Duke State
3. Address of Operator Box 1311, Big Spring, Texas 79720	9. Well No. 16
4. Location of Well UNIT LETTER C , 1838 FEET FROM THE West LINE AND 1284 FEET FROM THE North LINE, SECTION 28 TOWNSHIP 18S RANGE 28E N.M.P.M.	10. Field and Pool, or Wildcat Artesia
15. Elevation (Show whether DF, RT, GR, etc.) 3545 Gr.	12. County Eddy

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Start work approx. 9/14/70

1. Spot 50 sk cement plug on bottom (TD 2048) through 2" EUE tubing using mud laden fluid as displacing medium.
2. Cut off 4-1/2" casing at 1180' & spot 25 sk cement plug at that point.
3. Pull 8-5/8" casing (680')
4. Spot 25 sk cement plug at 680'
5. Spot 25 sk cement plug at 280' (Bottom of 10" casing)
6. Place 10 sk cement plug in top of 10" casing & set 4-1/2" OD pipe marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J. M. Denson TITLE **Asst. District Mgr. of Prod.** DATE **8/21/70**

APPROVED BY W. A. Gressett TITLE **OIL AND GAS INSPECTOR** DATE **AUG 25 1970**

CONDITIONS OF APPROVAL, IF ANY: