

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

RECEIVED
NEW MEXICO OIL CONSERVATION COMMISSION
JAN 11 1973
C. O. C.
ARTESIA, OFFICE

Form C-103
 Supersedes Old
 C-102 and C-103
 Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B-6811

SUNDRY NOTICES AND REPORTS ON WELLS
 (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
 USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator KERSEY & COMPANY	8. Farm or Lease Name Featherstone
3. Address of Operator P. O. Box 316, Artesia, New Mexico 88210	9. Well No. 2
4. Location of Well UNIT LETTER A , 1060 FEET FROM THE North LINE AND 250 FEET FROM THE East LINE, SECTION 29 TOWNSHIP 18S RANGE 28E NMPM.	10. Field and Pool, or Wildcat Artesia Queen Grayburg SA
15. Elevation (Show whether DF, RT, GR, etc.)	12. County Eddy

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
 NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set Halliburton Bridging Plug at approximately 1850' with 5 sacks of cement on plug.
2. Shot 5 1/2" casing off at 1550'. Put 100' cement plug in and out of 5 1/2" casing. Mudded hole back to 3 5/8" casing.
3. Put 25 sack cement plug in and out of 8 5/8" casing.
4. Shot 8 5/8" casing off at approximately 240'. Put 25 sack cement plug in and out of this casing.
5. Mudded hole back to surface and set marker in cement.

*Casing left in hole 8 5/8" - from 240 - 555
 5 1/2" " 1550 - 2261*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *Harold Kersey* TITLE Owner DATE January 3, 1973

APPROVED BY *[Signature]* TITLE SEALED DATE JUN 7 1974

CONDITIONS OF APPROVAL, IF ANY: