

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	/
FILE	/ ✓
U.S.G.S.	
LAND OFFICE	✓
OPERATOR	/

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. <b>B 9603 (2)</b>	
7. Unit Agreement Name	
8. Farm or Lease Name <b>Cowell State</b>	
9. Well No. <b>2</b>	
10. Field and Pool, or Wildcat <b>Artesia</b>	
12. County <b>Eddy</b>	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator <b>American Petrofina Company of Texas</b>
3. Address of Operator <b>Box 1311, Big Spring, Texas 79720</b>
4. Location of Well UNIT LETTER <b>K</b> , <b>1532</b> FEET FROM THE <b>South</b> LINE AND <b>2088</b> FEET FROM THE <b>West</b> LINE, SECTION <b>4</b> TOWNSHIP <b>18S</b> RANGE <b>28E</b> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) <b>3650 Gr.</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Spot 25 sk. cm. plug on bottom through 2" tubing using 10# mud as displacement fluid.
  2. Cut 4½" casing off 1100' and pull.
  3. Spot 25 sk. cement plug at stub of 4½" casing.
  4. Spot 25 sk. cement plug at 231' (Bottom of 8 5/8" casing).
  5. Place 5 sk. cement plug at surface and set 4½" pipe marker in top of 8 5/8" casing.
- This work should commence on or about August 19, 1968.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Cliff Chapman **Cliff Chapman** TITLE Petroleum Engineer DATE July 26, 1968

APPROVED BY W. A. Gressett TITLE OIL AND GAS INSPECTOR DATE AUG 6 1968

CONDITIONS OF APPROVAL, IF ANY: