

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	/
FILE	/
U.S.G.S.	
LAND OFFICE	
OPERATOR	/

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.		

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator American Petrofina Company of Texas	8. Farm or Lease Name Levers St.
3. Address of Operator Box 1311 Big Spring, Texas 79720	9. Well No. 11
4. Location of Well UNIT LETTER I 1578 FEET FROM THE South LINE AND 235 FEET FROM THE East LINE, SECTION 45 TOWNSHIP 18S RANGE 28E NMPM.	10. Field and Pool, or Wildcat Artesia
15. Elevation (Show whether DF, RT, GR, etc.) 3650 Gr.	12. County Eddy

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Spot 50 sk. cement plug on bottom through 2" tubing using 10# mud as displacement fluid.
2. Pull 2175 ft. of 7" casing. - (10-15-68)
3. Spot 25 sk. cement plug at stub of 7" casing.
4. Pull 8 5/8" casing (621 ft.).
5. Spot 25 sk. cement plug at stub of 8 5/8" casing.
6. Spot 25 sk. cement plug at 185 ft. (bottom of 10").
7. Place 5 sk. cement plug at surface and set 4 1/2" pipe marker in top at 10" casing.

Work should be started on or about August 15, 1968.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Cliff Chapman</u> Cliff Chapman	TITLE <u>Petroleum Engineer</u>	DATE <u>July 26, 1968</u>
APPROVED BY <u>W. A. Gressett</u>	TITLE <u>OIL AND GAS INSPECTOR</u>	DATE <u>AUG 6 1968</u>
CONDITIONS OF APPROVAL, IF ANY: <u>1. 7 days to start work on August 15, 1968.</u>		