

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT  
ARTESIA, NM 88210

Form approved.  
Budget Bureau No. 1004-0135  
Expires August 31, 1985

C/SF

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT" for such proposals.)

1. NAME OF OPERATOR  
Yates Petroleum Corporation

2. ADDRESS OF OPERATOR  
207 South 4th St., Artesia, NM 88210

3. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.  
See also space 17 below.)  
At surface

990 FNL & 330 FEL, Sec. 1-18S-29E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3537' KB

5. LEASE DESIGNATION AND SERIAL NO.

LC 051102-B

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME  
Ballard B

9. WELL NO.  
5

10. FIELD AND POOL, OR WILDCAT  
Loco Hills-O-G-SA

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

Unit A, Sec. 1-T18S-R29E

12. COUNTY OR PARISH  
Eddy

13. STATE  
NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐  
FRACTURE TREAT ☐  
SHOOT OR ACIDIZE ☐  
REPAIR WELL ☐  
(Other) ☐

PCLL OR ALTER CASING ☐  
MULTIPLE COMPLETE ☐  
ABANDON\* ☒  
CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐  
FRACTURE TREATMENT ☐  
SHOOTING OR ACIDIZING ☐  
(Other) ☐

REPAIRING WELL ☐  
ALTERING CASING ☐  
ABANDONMENT\* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) \*

Propose to plug well as follows:

1. Spot sufficient cement across producing interval to tie back 50' into production casing shoe. Tag plug.
2. Isolate Queen formation from overlying zones with 100' cement plug. Top of Queen is at 2266'; top of cement is at 1055'.
3. Perforate 50' below base of salt at 1120' and squeeze with 50 sx cement, leaving 100' plug in casing. Tag plug.
4. Perforate 50' above top of salt at 420' and squeeze with 50 sx cement, leaving 100' plug in casing. Tag plug.
5. Set 50' surface plug and install regulation abandonment marker. Both sides of csg.

NOTE: 1) NOTIFY BLM, CARLSBAD, NM, (887-6544) 24 HOURS PRIOR TO BEGINNING WORK.

2) Mud between plugs to be 10#/gallon mud-laden fluid.

18. I hereby certify that the foregoing is true and correct

SIGNED James A. Goodlett

TITLE Production Supervisor

DATE 11-26-85

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE 12-10-85

CONDITIONS OF APPROVAL, IF ANY:

\*See Instructions on Reverse Side