

arcsa

UNITED STATES

DEPARTMENT OF THE INTERIOR

GEOLOGICAL SURVEY

BUDGET DIRECT NO. 42-N1424

CBF

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☐ well ☐ gas ☐ well ☐ other ☒ WIW-Ta

2. NAME OF OPERATOR
Newmont Oil Company ✓

3. ADDRESS OF OPERATOR
P.O. Box 1305 Artesia, New Mexico 88210

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE: 1310/8 1310/8
AT TOP PROD. INTERVAL:
AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO: SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF	<input type="checkbox"/>	<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>	<input type="checkbox"/>
SHOOT OR ACIDIZE	<input type="checkbox"/>	<input type="checkbox"/>
REPAIR WELL	<input type="checkbox"/>	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>	<input type="checkbox"/>
MULTIPLE COMPLETE	<input type="checkbox"/>	<input type="checkbox"/>
CHANGE ZONES	<input type="checkbox"/>	<input type="checkbox"/>
ABANDON*	<input type="checkbox"/>	<input checked="" type="checkbox"/>
(other)		

5. LEASE
LC 062072

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME
West Loco Hills GRB # 4 SD

8. FARM OR LEASE NAME
Tract 17

9. WELL NO.
3

10. FIELD OR WILDCAT NAME
Loco Hills (Q.G.SA)

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
10-18-29

12. COUNTY OR PARISH
Eddy

13. STATE
New Mexico


14. API NO.
3478

15. ELEVATIONS (SHOW DF, KDB, AND WD)

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

3-31-83 125 sacks @ 2572'.
 4-4-83 Tag @ 2444'. Squeeze 60 sacks thru hole in casing @ 925'.
 4-5-83 Tag @ 922'. Test to 500 PSI. Held 5 minutes. 25 sacks @ 920'.
 4-5-83 Perforate @ 370'. Held 1000 PSI for 20 minutes.
 4-5-83 Squeeze 55 sacks into braden head.
 4-5-83 75 sacks 420' to surface.
 4-6-83 Squeeze 25 sacks into braden head.
 4-10-83 Held 500 PSI for 10 minutes (braden head.).
 4-10-83 Install dry hole marker.



Subsurface Safety Valve: Manu. and Type _____ Set @ _____ FT.

18. I hereby certify that the foregoing is true and correct

SIGNED [Signature] TITLE Area Manager DATE 7/20/83

(This space for Federal or State office use)

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY:Post 70-2
12-2-83
p4A