

Expires August 31, 1985

**SUNDRY NOTICES AND REPORTS ON WELLS**

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT" for such proposals.)

5. LEASE DESIGNATION AND SERIAL NO.

NM - 14843

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

Ballard Grayburg San Andres U

8. FARM OR LEASE NAME

Tract No. 20

9. WELL NO.

11

10. FIELD AND POOL, OR WILDCAT

Loco Hills-Queen-Grayburg-SA

11. SEC., T., R., M., OR BLM. AND  
SURVEY OR AREA

17 - 18S - 29E

12. COUNTY OR PARISH

Eddy

13. STATE

New Mexico

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3500' GL

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON\*

REPAIR WELL

CHANGE PLANS

(Other) Repair Waterflow

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT\*

(Other)

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

1. RUPU; TOH with rods and tubing.
2. Set CIBP above perms.
3. Run Cement Bond Log to find cement top.
4. Perf 4 squeeze holes at cement top.
5. Establish circulation to surface and circulate cement. If cannot establish circulation:
  - A. Pump enough cement to bring cement to base of Salt.
  - B. Run T° Survey to check cement top.
  - C. Tie onto braidenhead and establish pump-in rate.
  - D. Run Tracer Survey to make sure fluid is going into Salt.
  - E. Braidenhead squeeze with enough cement to fill annulus between 8-5/8" & 5 1/2" casing; this will isolate top of Salt.
6. GIH with bit and Drill Collars.
7. Drill out cement and CIBP to TD; TOH.
8. Run tubing and rods.
9. Return well to pump.

Note: Have verbal approval from Bob Fitschke and Les Clements to proceed as outlined above.

18. I hereby certify that the foregoing is true and correct

SIGNED Mike Brunell

TITLE Field Foreman

DATE January 18, 1985

(This space for Federal or State office use)

APPROVED BY \_\_\_\_\_

TITLE APCA MANAGER

DATE 1-22-85

CONDITIONS OF APPROVAL, IF ANY:

\*See Instructions on Reverse Side

Ballard 20-11

1/17/85

