

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRI  
(Other Instructio  
verse side)

Form approved.  
Budget Bureau No. 1004-0135  
Expires August 31, 1985

9. LEASE DESIGNATION AND SERIAL NO.

NM-015068

10. IF INDIAN, ALLEGED OR TRIBE NAME

11. UNIT AGREEMENT NAME

12. FARM OR LEASE NAME

McKee Wilson

13. WELL NO.

5

14. FIELD AND POOL, OR WILDCAT

Turkey Track SR O Grbg SA

15. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

Sec. 34-T18S-R29E

16. COUNTY OR PARISH

Eddy

17. STATE

N.M.

1.

OIL  
WELL ☒ GAS  
WELL ☐ OTHER

2. NAME OF OPERATOR

Marbob Energy Corporation ✓

MAY 12 '89

3. ADDRESS OF OPERATOR

P.O. Drawer 217, Artesia, N.M. 88210

C. C. D.

ARTESIA OFFICE

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.)

See also space 17 below.)  
At surface

1650 FNL 2310 FWL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3420' GR

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON\*

REPAIR WELL

CHANGE PLANS

(Other)

<input type="checkbox"/>
<input type="checkbox"/>
<input type="checkbox"/>
<input checked="" type="checkbox"/>
<input type="checkbox"/>

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT\*

(Other)

<input type="checkbox"/>
<input type="checkbox"/>
<input type="checkbox"/>

<input type="checkbox"/>
<input type="checkbox"/>
<input type="checkbox"/>

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

We propose to plug & abandon as follows:

Set 100' plug from 2100'-2000'; run free point; shoot csg  
off @ 1800'; set 100' plug 50' in and out of stub; set  
150' plug @ 675'-775'; set 100' plug @ 375'-275'; set 50'  
plug @ surface. Install dry hole marker and clean location.

I hereby certify that the foregoing is true and correct

SIGNED

Rhonda Nelson

TITLE

Production Clerk

DATE

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

\*See Instructions on Reverse Side