

Form 9-331
(May 1963)UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPPLICATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS RECEIVED

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		OCT 27 1965	
2. NAME OF OPERATOR		TEXACO Inc. ✓	
3. ADDRESS OF OPERATOR		P. O. Box 728 - Hobbs, New Mexico	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface		Well located 330' from the North Line, and 1650' from the East Line of Section 22, T-18-S, R-30-E, Eddy County, New Mexico.	
14. PERMIT NO.	15. ELEVATIONS (Show whether DF, RT, GR, etc.)	7. UNIT AGREEMENT NAME	8. FARM OR LEASE NAME
Regular	3463' (D. F.)	NONE	L.R. Manning Fed. "a"
		9. WELL NO.	10. FIELD AND POOL, OR WILDCAT
		1	Leo
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA	12. COUNTY OR PARISH
		Sec. 22, 18-S, R-30-E	Eddy
		13. STATE	
		N. M.	

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☐
REPAIR WELL ☐
(Other) ☐

PULL OR ALTER CASING ☐
MULTIPLE COMPLETE ☐
ABANDON* ☒
CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐
FRACTURE TREATMENT ☐
SHOOTING OR ACIDIZING ☐
(Other) ☐

REPAIRING WELL ☐
ALTERING CASING ☐
ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log (Form 9-332).)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all depths and zones pertinent to this work.)*

We propose to plug and abandon subject well as follows:

1. Pull rods, tubing, and all pump equipment.
2. Spot 100 Sx. cement from total depth of 3133' to approx. 2950'.
3. Cut off and recover 7" O. D. Casing from approx. 1900'.
4. Spot 40 Sx. cement from 50' below, and 50' above of non-recoverable 7" casing.
5. Spot 50 Sx. cement from 475' to 575', over seat of surface casing.
6. Spot 20 Sx. cement from 0' to 50'.
7. Clean location for inspection as per the United States Department of The Interior Geological Survey regulations, install 4" marker extending 4' above ground level.

18. I hereby certify that the foregoing is true and correct


SIGNED

Dan Gillett

TITLE Assistant District Superintendent

DATE October 25, 1965

(This space for Federal or State office use)



TITLE

Spot a cement plug at least
20' in length on
the outside of the 4" surface casing

*See Instructions on Reverse Side