

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

N. M. O. C. C. COPY

SUBMIT IN TRIPLICATE
(Other instructions on
reverse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC-028978-B

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

North Benson Queen Unit

8. FARM OR LEASE NAME

North Benson Queen Unit

9. WELL NO.

35

10. FIELD AND POOL, OR WILDCAT
Queen Grayburg North

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 34, T-18-S, R-30-E

12. COUNTY OR PARISH

Eddy

13. STATE
New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL ☐ GAS WELL ☐ OTHER Water Injection

2. NAME OF OPERATOR

TEXACO Inc.

3. ADDRESS OF OPERATOR

P.O. Box 728 Hobbs, New Mexico 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface

Well is located 660' FNL & 610' FWL of
Section 34, T-18-S, R-30-E, Unit Letter "D", Eddy,
County, New Mexico

14. PERMIT NO.

Regular

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3458' (GR)

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other) Addl perfs in same zone

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT*

(Other)

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-
nent to this work.) *

1. Rig Up. Install BOP. Pull injection tubing & packer.
2. Set RBP @ 3270' & packer @ 3230'. Attempt to establish pump rate.
3. Perforate 4-1/2" Csg W/2-JSPF @ 3250'.
4. Set CIBP @ 3270', Squeeze 4-1/2" Csg perforation 3250' w/100 sx
Class 'C' cement. WOC 24 hrs drill out to ID - 3387'. Test.
5. Reperforate 4-1/2 Csg w/2-JSPF @ 3323', 3325', 3333'. (Interval
previously perforated but no water intering interval).
6. Set packer @ 3315' Acidize perforations 3323'-3333'. w/2000 gal
mud Acid.
7. Run injection tubing & packer. Test & return to injection.

RECEIVED RECEIVED

JUL 21 1976

JUL 19 1976

O. C. C.
ARTESIA, OFFICE

U. S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Asst. Dist. Supt.

DATE 7-15-76

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

COMBINATION OF APPROVAL, IF ANY:

APPROVED

JUL 19 1976

L. L. BEEKMANN
ACTING DISTRICT ENGINEER

*See Instructions on Reverse Side