


DISTRICT I
P.O. Box 1980, Hobbs NM 88240

DISTRICT II
811 South First, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd, Aztec, NM 87401



CONSERVATION DIVISION
1040 South Pacheco
Santa Fe, New Mexico 87505

WELL API NO.
30-015-10207

5. Indicate Type of Lease
STATE ☒ FEE ☐

6 State Oil & Gas Lease No.
B-3627

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS).

1. Type Of Well:
OIL ☒ GAS ☐
WELL WELL ☐ OTHER

2. Name of Operator
Mack Energy Corporation

3. Address of Operator
P.O. Box 960, Artesia, NM 88211-0960

4. Well Location
Unit Letter N : 660 Feet From The South Line and 660 Feet From The West Line
Section 36 Township 17S Range 31E NMPM Eddy County

8. Well No.
1

9. Pool name or Wildcat
Tamano San Andres

10. Elevation (Show whether DF, RKB, RT, GR, etc.)
3815' GR

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER: <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Mack Energy Corporation proposes to plug and abandon well as follows:

1. Notify OCD 24 hours before starting plugging operations.
2. ~~Spot 200~~ cement plug from 4345-4350'. 25 sz. plug @ 4345' - TAG
3. ~~Spot 100~~ cement plug from 1169-1069' 50' above and below 8 5/8 casing shoe. Perf. csq @ 2280' - Place 100' of cmt. inside & outside of csq. - TAG (2280'-2180')
4. ~~Spot 200~~ surface plug. Perf. csq. @ 60' - Circ cmt. to Surface.
5. Install dry hole marker. Perf. csq. @ 1169' - Place 100' of cmt. inside & outside of csq. - TAG (1169'-1069')

Salt gel mud consisting of 10#
Brine W/25# of gel per bbl
must be placed between each plug

I hereby certify that the information above is true and complete to the best of my knowledge and belief

SIGNATURE Crissa D. Carter TITLE Production Analyst DATE 2/7/2003

TYPE OR PRINT NAME

Crissa D. Carter

TELEPHONE NO

(This space for State Use)

APPROVED BY [Signature] TITLE Wild Sep II DATE FEB 17 2003

CONDITIONS OF APPROVAL, IF ANY: