

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

OIL CONSERVATION DIVISION  
P.O. Box 2088

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

Santa Fe, New Mexico 87504-2088

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

JUL -19 1992

WELL API NO.
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. L-1605
7. Lease Name or Unit Agreement Name State "AR"
8. Well No. 1
9. Pool name or Wildcat Wildcat ABO

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/> P & A	
2. Name of Operator McClellan Oil Corporation	
3. Address of Operator P.O. Drawer 730, Roswell, N.M. 88202	
4. Well Location Unit Letter F : 1980 Feet From The North Line and 1980 Feet From The West Line Section 31 Township 18S Range 23East NMPM Eddy County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4083.6' GL	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐  
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to P&A as follows:

8 5/8" csg - 1816' cir. 2 3/8" tbgr.  
4 1/2" Csg. T.O.C. = 3620'  
Perfs 4386-4456'

1. Load hole w/heavy gel H<sub>2</sub>O.
2. 1st plug 4456-4256'. 30sx - 3% CaCl<sub>2</sub> & tag.
3. Cut csg. off at 3500' & pull out of hole.
4. Run tbgr. to 3550' 2nd plug 3550'-3450' - 30sx & tag.
5. 3rd plug 2550'-2450' - 30 sx.
6. 4th plug 1866'-1766' - 30 sx.
7. 5th plug 800'-700' - 25 sx.
8. 6th plug 60' & cir. cmt. to surface.
9. Install dry hole marker & clean location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE [Signature] TITLE Drlg, & Comp. Eng. DATE 7-13-92

TYPE OR PRINT NAME

TELEPHONE NO.

(This space for State Use)

APPROVED BY [Signature] TITLE Field Rep DATE 8/12/92

CONDITIONS OF APPROVAL, IF ANY: