

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

# NEW MEXICO OIL CONSERVATION COMMISSION

RECEIVED

JUN 25 1970

O. C. C.  
ARTESIA, OFFICE

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	E-5461

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- T.A. Well	7. Unit Agreement Name
2. Name of Operator Atlantic Richfield Company	8. Farm or Lease Name Hondo "C" State
3. Address of Operator P. O. Box 1978, Roswell, New Mexico 88201	9. Well No. 1
4. Location of Well UNIT LETTER D, 330 FEET FROM THE North LINE AND 990 FEET FROM THE West LINE, SECTION 2 TOWNSHIP 18-S RANGE 27-E NMPM.	10. Field and Pool, or Wildcat
15. Elevation (Show whether DF, RT, GR, etc.) 3616' DF	12. County Eddy

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐  
OTHER ☐

PLUG AND ABANDON ☒  
CHANGE PLANS ☐  
OTHER ☐

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOBS ☐  
OTHER ☐

ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐  
OTHER ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well was temporarily abandoned in 1952 by Malco Refineries, Inc., by plugging back with cement from T.D. of 8725' to 3664' (4 plugs). It has developed a surface water leak. We propose to P & A as follows:

- Shoot off and recover 7" 17# casing from as deep as possible (estimated top of cement at 3500-3600').
- Set these neat cement plugs, using 9# salt gel mud to spot same. 40 sx (100') in and out of 7" stub 160 sx (400') from 1800-1400' 40 sx across 8-5/8" shoe @ 935'.
- Either run 1" outside 8-5/8" & circulate cement from 550-350', or shoot 4 holes in 8-5/8" @ 550' and circulate cement behind 8-5/8".
- Place 10 sx cement in top of well, erect dry hole marker and clean and level location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED A.L. Britches

TITLE Dist. Drlg. Supervisor

DATE 6/24/70

APPROVED BY B.L. Stamm

TITLE OIL AND GAS INSPECTOR

DATE JUN 25 1970

CONDITIONS OF APPROVAL, IF ANY: Notify N.M.O.C.C. in sufficient time to witness

Plugging from 1800' up