

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO.	30-015-10802
5. Indicate Type of Lease	STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.	State 647AC724
7. Lease Name or Unit Agreement Name	Artesia Queen Graybury San Andres
8. Well No.	210
9. Pool name or Wildcat	San Andres
10. Elevation (Show whether DF, RKB, RT, GR, etc.)	
3564' GR	

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:	OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator	DEKALB Energy Company % Steve Smith
3. Address of Operator	P.O. Box 10513, Bakersfield, CA 93389
4. Well Location	Unit Letter B : 440 Feet From The North Line and 1980 Feet From The East Line Section 31 Township 18S Range 28E NMPM Eddy County
10. Elevation (Show whether DF, RKB, RT, GR, etc.)	
3564' GR	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐  
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Remove tubing, if any, and clean out casing to 1906'. Cement across perforations, (1890'- 1906') with 35 sacks "G" cmt. Tag cmt. top or set bridge plug above.
2. Perforate 4½" casing at 1490' and squeeze 25 sacks "G" cmt. from 1450'.
3. Perforate 4½" casing at 570' and squeeze 30 sacks "G" cmt. from 450'.
4. Mix 12 sacks "G" cmt. and fill 4½" and 8 5/8" casing at surface.
5. Drilling mud will be placed between all cement plugs.
6. Cut off casing below ground level and install well marker.
7. Work to start as soon as rig available.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Steve Smith TITLE Agent DATE 9/25/93  
TYPE OR PRINT NAME Steve Smith (805) 833-1032 TELEPHONE NO.

(This space for State Use)

APPROVED BY [Signature] TITLE Field Rep II DATE 11-10-93