

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals, and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO.	30-015-10802
5. Indicate Type of Lease	STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.	State 647 AC724
7. Lease Name or Unit Agreement Name	Artesia Queen Graybury San Andres
8. Well No.	210
9. Pool name or Wildcat	San Andres ART. 6 FSA

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	
2. Name of Operator DEKALB Energy Company % Steve Smith	
3. Address of Operator P.O. Box 10513, Bakersfield, CA 93389	
4. Well Location Unit Letter B : 440 Feet From The North Line and 1980 Feet From The East Line Section 31 Township 18S Range 28E NMPM Eddy County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3564' GR	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐  
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☒  
CASING TEST AND CEMENT JOB ☐  
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

11/15/93 Move in and rig up Baber rig. Pick up 2 3/8" tubing and run in hole to 1914'. Equalize 35 sacks cement. Trip out of hole, SDFN.

11/16/93 Trip in hole and tag top of cement at 1874'. Change hole over to salt gel. Equalize 25 sacks cement from 1874'. Trip out of hole, R/U wireline, shoot 4 holes at 1490'. Trip in hole with cement retainer, set at 1420'. Unable to obtain breakdown rate, pressured up to 1000#, and held. Pull out of retainer, and equalize 25 sacks cement. Trip out of hole with tubing, R/U wireline, shoot 4 holes at 570'. Trip in hole with 5 1/2" cement retainer and squeeze 30 sacks cement from 450'. Mixed 12 sacks cement and filled 5 1/2" and 8 5/8" casing to surface. Lay down rig and move off location. Remove anchors, and weld on well marker.

11/17/93 Clean and restore location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Steve Smith TITLE Agent DATE 11/17/93  
TYPE OR PRINT NAME Steve Smith (805) 833-1032 TELEPHONE NO.

(This space for State Use)

*Robert Palmer*

DATE