

**NMOCC COPY**  
**UNITED STATES**  
**DEPARTMENT OF THE INTERIOR**  
**GEOLOGICAL SURVEY**

SUBMIT IN TRIPLICATE  
(Other instructions on reverse side)

*Copy to SF*  
Form approved.  
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC-028978 (A)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

**SUNDRY NOTICES AND REPORTS ON WELLS**

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT" for such proposals.)

**RECEIVED**

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

MAY - 4 1978

2. NAME OF OPERATOR

TEXACO Inc. ✓

3. ADDRESS OF OPERATOR

P.O. Box 728 Hobbs, New Mexico 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\* See also space 17 below.)

At surface 1980' FWL & 660' FNL of Section 21,  
T-18-S, R-30-E, Unit Letter C, Eddy County, New Mexico.

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

L.R. Manning Fed #

9. WELL NO.

5

10. FIELD AND POOL, OR WILDCAT

Lee Queen Grayburg

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec 21, T-18-S, R-30-E

14. PERMIT NO.

Regular

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3481' (DF)

12. COUNTY OR PARISH

Eddy

13. STATE

New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON\*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT\*

(Other)

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

1. Rigged Up.
2. Set CIBP @ 2550' and dump 4 sx sand on plug.
3. Perforate 4-1/2" OD Csg w/2-Jts @ 1400'. Could not pump in.
4. Spot 25 sx cement plug from 1500'-1175'.
5. Perforate 4-1/2" OD Csg W/2-JS @ 526'.
6. Squeeze perforation w/200 sx Class H cement. Cement to surface.
7. Install Dry Hole Marker & Clean Up. Well P&A 4-19-77.

**RECEIVED**

MAY 02 1977

U.S. GEOLOGICAL SURVEY  
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Asst. Dist. Supt.

DATE

4-28-77

(This space for Federal or State office use)

APPROVED BY

TITLE

ACTING DISTRICT ENGINEER

DATE

MAY 3 - 1978

CONDITIONS OF APPROVAL, IF ANY:

\*See Instructions on Reverse Side

*Post to  
SF  
P&A*