Form 3160-5 (August 1999)	UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT RY NOTICES AND REPORTS ON WELLSIA, NM 88210- this form for proposals to drill or to re-enter an					Expires November 30, 2000			
SUNDH Do not use th abandoned w	his form for proposals to ell. Use Form 3160-3 (APE	drill) for	or to re-enter such proposal	an s.	1	6. If Indi	an, All	ottee or Tribe Name	
SUBMIT IN TR	NPLICATE - Other instru	ıctio	ons on reverse	side		7. If Unit	t or CA	/Agreement, Name and/or N	
1. Type of Well Type of Well Gas Well Other						8. Well 1	Name a	ind No.	
2. Name of Operator						WLHU G4S Unit Tract 9-3			
Yates Petroleum (Corporation				· · · · · · · · · · · · · · · · · · ·	9. API V		v	
3a. Address	•	one No. (<i>include area code</i>))5-748-1471			30-015-20816 10. Field and Pool, or Exploratory Area Loco Hills-Queen-GB-SA				
105 S. 4th St	505-740-14								
4. Location of Well (Footage, Sec., T., R., M., or Survey Description)						11. County or Parish, State			
990' FSL & 1310'	FEL of Section 3-T1	L8S-	R29E (Unit	P, 8	SESE)		F.	Idu Co NM	
	<u> </u>							Idy Co., NM	
12. CHECK AI	PPROPRIATE BOX(ES) TO		DICATE NATU	RE O	F NOTICE,	REPORT, C			
TYPE OF SUBMISSION			T	PE O	F ACTION	<u> </u>			
<u> </u>			Deepen		Production (St	art/Resume)		Water Shut-Off	
X Notice of Intent	Alter Casing		Fracture Treat		Reclamation			Well Integrity	
Subsequent Report	Casing Repair		New Construction		Recomplete			Other	
Subsequent Report	Change Plans	_	Plug and Abandon		Temporarily A				
Final Abandonment Notice 13. Describe Proposed or Complete	Convert to Injection		Plug Back	U	•				
following completion of the in- testing has been completed. F determined that the site is ready	volved operations. If the operations is the operation of	n resu be file	only after an requ	imated ons and with i spletion iremer	or recompletions, including re	n in a new int clamation, hav	erval, a ve been	completed, and the operato	
following completion of the in- testing has been completed. F determined that the site is ready Propose to plug at 1. TOOH with 2-7 2. TIH with wire Load hole with pl 3. Spot a 25 sac 4. Perforate 4-1 5. TIH with wire tubing. If neces injection rate. retainer. TOOH w 6. Nipple down B TOOH. TIH with t	volved operations. If the operations imal Abandonment Notices shall by for final inspection.) nd abandon as follo /8" tubing. line set CIBP and s ugging mud. Keep w k Class C cement pl /2" casing with 6 H line set cement ret sary, load hole with Squeeze with 75 sac with tubing. GOP. TIH with wire subing. If necessar	set vell lug nole tain th p cks line ry, wit	CIBP at 260 bore loaded from 2600-2 es at 1000' ner and set olugging mud Class C cen e set cement load hole w th 55 sacks	ol'. wi 300 and ret.	TOOH. th pluggi '. TOOH 6 holes ainer at Sting int . Leave tainer ar plugging Class C c	TIH with ng mud. with tub at 442': 950'. T o retain 35' of c d set re ; mud. S ement fu	tul oing 245 100H her cemei stai	or completed, and the operato or ing & tag CIBP. TIH with and establish nt on top of ner at 342'. g into retainer 442-342'. Leave	
following completion of the in- testing has been completed. F determined that the site is ready Propose to plug at 1. TOOH with 2-7 2. TIH with wire Load hole with pl 3. Spot a 25 sac 4. Perforate 4-1 5. TIH with wire tubing. If neces injection rate. retainer. TOOH w 6. Nipple down B TOOH. TIH with t and establish cir <u>35' of coment on</u> 14. I hereby certify that the forego Name (Printed/Typed)	volved operations. If the operations imal Abandonment Notices shall by for final inspection.) nd abandon as follo /8" tubing. line set CIBP and s ugging mud. Keep w k Class C cement pl /2" casing with 6 H line set cement ret sary, load hole with Squeeze with 75 sac with tubing. GOP. TIH with wire subing. If necessar	set vell lug nole tain th p cks line ry, wit	CIBP at 260 bore loaded from 2600-2 es at 1000' ner and set olugging muc Class C cer set cement load hole t th 55 sacks I with tubi	ol'. wi 300 and ret.	TOOH. th pluggi '. TOOH 6 holes ainer at Sting int . Leave tainer ar plugging Class C c	TIH with ng mud. with tub at 442': 950'. T o retain 35' of c d set re mud. S ement fu ON NEXT	tul oing 245 COOH ner cemei stai rom PAG	or completed, and the operato or ing & tag CIBP. TIH with and establish nt on top of ner at 342'. g into retainer 442-342'. Leave	
following completion of the in- testing has been completed. F determined that the site is ready Propose to plug at 1. TOOH with 2-7 2. TIH with wire Load hole with pl 3. Spot a 25 sac 4. Perforate 4-1 5. TIH with wire tubing. If neces injection rate. retainer. TOOH w 6. Nipple down B TOOH. TIH with t and establish cir <u>35' of coment on</u> 14. Thereby certify that the forego Name (Printed/Typed) Rusty Klein	volved operations. If the operations imal Abandonment Notices shall by for final inspection.) nd abandon as follo /8" tubing. line set CIBP and s ugging mud. Keep w k Class C cement pl /2" casing with 6 H line set cement ret sary, load hole with Squeeze with 75 sac with tubing. GOP. TIH with wire subing. If necessar	set vell lug nole tain th p cks line ry, wit	CIBP at 260 bore loaded from 2600-2 es at 1000' ner and set olugging mud Class C cen e set cement load hole w th 55 sacks	00'. win 300 and ret. hent cre vith of 39. C Ope	TOOH. th pluggi '. TOOH 6 holes ainer at Sting int . Leave tainer ar plugging Class C c ONTINUED rations ?	TIH with ng mud. with tub at 442': 950'. T o retair 35' of c d set re mud. S cement fr ON NEXT Cechnici.	tul oing 245 COOH ner cemei stai rom PAG	or completed, and the operato or ing & tag CIBP. TIH with and establish nt on top of ner at 342'. g into retainer 442-342'. Leave	
following completion of the in- testing has been completed. F determined that the site is ready Propose to plug at 1. TOOH with 2-7 2. TIH with wire Load hole with pl 3. Spot a 25 sac 4. Perforate 4-1 5. TIH with wire tubing. If neces injection rate. retainer. TOOH w 6. Nipple down B TOOH. TIH with t and establish cir <u>35' of coment on</u> 14. I hereby certify that the forego Name (Printed/Typed)	volved operations. If the operations inal Abandonment Notices shall by y for final inspection.) nd abandon as follo /8" tubing. line set CIBP and s ugging mud. Keep w k Class C cement pl /2" casing with 6 H line set cement ref sary, load hole with Squeeze with 75 sac with tubing. GOP. TIH with wire culation. Squeeze top of retainer.	set vell lug nole tain th p cks line ry, wit	CIBP at 260 bore loaded from 2600-2 es at 1000' her and set olugging muc Class C cer load hole to th 55 sacks with tubis Title Date	ol'. wiremer 300 and ret. and ret. c of <u>of</u> C Ope Mar	TOOH. TOOH. th pluggi TOOH th oles ainer at Sting int Leave tainer ar plugging Class C co ONTINUED rations C	TIH with ng mud. with tub at 442': 950'. T o retain 35' of c d set re mud. S ement fu ON NEXT Cechnici	tul oing 245 COOH ner cemei stai rom PAG	or completed, and the operato or ing & tag CIBP. TIH with and establish nt on top of ner at 342'. g into retainer 442-342'. Leave	
following completion of the in- testing has been completed. F determined that the site is ready Propose to plug at 1. TOOH with 2-7 2. TIH with wire Load hole with pl 3. Spot a 25 sac 4. Perforate 4-1 5. TIH with wire tubing. If neces injection rate. retainer. TOOH w 6. Nipple down B TOOH. TIH with t and establish cir <u>35' of coment on</u> 14. Thereby certify that the forego Name (Printed/Typed) Rusty Klein	volved operations. If the operations inal Abandonment Notices shall by y for final inspection.) nd abandon as follo /8" tubing. line set CIBP and s ugging mud. Keep w k Class C cement pl /2" casing with 6 H line set cement ref sary, load hole with Squeeze with 75 sac with tubing. GOP. TIH with wire culation. Squeeze top of retainer.	set vell lug nole tain th p cks line ry, wit TOOH	CIBP at 260 bore loaded from 2600-2 es at 1000' her and set olugging muc Class C cer e set cement load hole to th 55 sacks with tubic Title Date	ol'. wi 300 and ret. and ret. c vith of C Ope Mar	TOOH. TOOH. th pluggi TOOH th oles ainer at Sting int Leave tainer ar plugging Class C co ONTINUED rations C	TIH with ng mud. with tub at 442': 950'. T o retain 35' of c d set re mud. S cement fr ON NEXT Cechnici.	tul oing 345 COOH her a cemen stin rom PAG an	or completed, and the operato or ing & tag CIBP. TIH with and establish nt on top of ner at 342'. g into retainer 442-342'. Leave	

MAR 16 2010 POSILINI

YATES PETROLEUM CORPORATION WLHU G4S Unit Tract #9-3 Section 3-T18S-R29E Eddy County, New Mexico

SUNDRY NOTICE CONTINUED:

Spot a 15 sack Class C cement plug at surface.
 Install regulation abandonment marker.

NOTIFY BLM-CARLSBAD (505-887-6544) AND OCD-ARTESIA (505-748-1283) 24 HOURS PRIOR TO COMMENCING PLUGGING OPERATIONS

Rusty Klei/

Operations Technician March 14, 2000



