drilling into the <u>Wolfcamp formation</u> and used until production casing is run and cemented. Monitoring equipment shall consist of the following:

- (1) A recording pit level indicator to determine pit volume gains and losses.
- (2) A mud volume measuring device for accurately determining mud volume necessary to fill the hole on trips.
- (3) A flow densor on the low-line to warn of any abnormal und returns from the yel?.
- 6. When coming out of the hole with drill pipe, the annulus shall be filled with mud before the and level drops below 150 feet. The volume of mud required to fill the hole shall be watched, and any time there is an indication of swabbing, or influx of formation fluids, proper blowout prevention predautions must be taken. The mud shall not be circulated and conditioned except on or near bottom, unluss well conditions prevent running the pipe to bottom.
- 7. A copy of these requirements shall be posted on the rig floor or in the dog house dooing the dritting of the well.

A star . Kazel Distria Engineer

Longe Rul	New Mexico 0214624
Well	Coquina Oil Corp. 1-Superior Mes.
Drillsite	(980/N&E 1-185-25E
Depth	8,800' Morriw
Approved	June 14, 1973