

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

RECEIVED

SEP 29 '94

NM OIL CONS COMMISSION
Drawer DD
Artesia, NM 88210

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

5. Lease Designation and Serial No.

LC-067136

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Scout EH Federal #3

9. API Well No.

30-015-70066

10. Field and Pool, or Exploratory Area

Penasco Draw San Andres Yeso

11. County or Parish, State

Eddy Co., NM

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

YATES PETROLEUM CORPORATION (505) 748-1471

3. Address and Telephone No.

105 South 4th St., Artesia, NM 88210

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

660' FNL & 1980' FEL of Section 34-T18S-R25E (Unit B, NWNE)

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

☒ Notice of Intent

☐ Subsequent Report

☐ Final Abandonment Notice

TYPE OF ACTION

☐ Abandonment

☒ Recompletion

☐ Plugging Back

☐ Casing Repair

☐ Altering Casing

☐ Other

☐ Change of Plans

☐ New Construction

☐ Non-Routine Fracturing

☐ Water Shut-Off

☐ Conversion to Injection

☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Propose to abandon Yeso perforations 2114-2260' and recompleat lower to the Wolfcamp at approximately 5680-5700' as follows:

1. POOH with rods, pump and tubing.
2. Fill casing with water. If casing will stand full and circulation can be maintained, proceed with drillout. If Yeso perforations take fluid and circulation cannot be maintained, squeeze Yeso perforations 2114-2260'.
3. RIH w/4-3/4" bit and drill out casing shoe and cement plug from 4110-4258'. Work thru plug to ream out. Clean out hole to 5800'.
4. Make dummy run with 4-1/2" gauge ring to 5800' to ensure that 4-1/2" casing will go.
5. Run open hole logs.
6. Run 4-1/2" flush joint casing to 5800'. Bring top of cement as high as possible. Try to cover Yeso perforations 2114-2260' with cement.
7. RIH w/bit and scraper and clean out 4-1/2" casing to float collar. Pressure test casing.
8. Run GR/CBL/CCL log.
9. Perforate - exact perms will follow based on open hole logs. Approximate depth of perforations will be 5680-5700'.

14. I hereby certify that the foregoing is true and correct

Signed

Title Production Clerk

Date Sept. 16, 1994

(This space for Federal or State office use)

Approved by

(J.G.S. S.D.) JOE G. LARA

Title

PETROLEUM ENGINEER

Date

9/27/94

Conditions of approval, if any:

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*See Instruction on Reverse Side