

TURKEY STATE #1
Section 32-18S-29E
Eddy County, NM

Existing Well Conditions

8 5/8 " @ 320' w/75 sacks Est. TOC - 150'
4 1/2" @ 2010 w/100 sacks TOC - 1550' by CBL

1. Set CIBP @ $\pm 1900'$
2. Spot 25 sack plug on CIBP - 1530-1900'
3. Run free point on 4 1/2 casing

A. If conditions indicate

4. Cut and pull 4 1/2" casing
5. Spot 25 sack cement plug on casing stub - TAG (50' in 50' out)
6. Spot 25 sack cement plug across 8 5/8" casing shoe - TAG.
7. Perforate 8 5/8 casing @ $\pm 125'$
8. Squeeze perforation with 50-75 sacks of cement (try to circulate)
9. Spot 25 sack plug inside 8 5/8" back to surface
10. Erect surface marker

B. OR

4. Leave 4 1/2" casing
6. ~~5.~~ Perforated 4 1/2" casing @ $\pm 370'$
7. ~~6.~~ Squeeze perforations w/ 75-150 sacks of cement (try to circulate)
8. ~~7.~~ Perforate 4 1/2" casing @ $\pm 125'$
9. ~~8.~~ Squeeze perforation w/ 50-75 sacks of cement
10. ~~9.~~ Spot 25 sack plug inside 4 1/2" casing back to surface
11. ~~10.~~ Erect surface marker

5. PERFOR 4 1/2" casing @ 200'
X seq. LEAVE 100' Casing
PLUG IN CBL

NOTIFY OED TO WITNESS TAG