

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OCT 30 1991

O. C. D.  
ARTESIA OFFICE

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>	
5. State Oil & Gas Lease No. E-1286	
7. Unit Agreement Name	
8. Farm or Lease Name Turkey Track Com	
9. Well No. 1	
10. Field and Pool, or Wildcat Undesignated GB-SA	
12. County Eddy	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL <input checked="" type="checkbox"/>	GAS WELL <input type="checkbox"/>	OTHER- <input type="checkbox"/>
Name of Operator Sol West III		
Address of Operator P. O. Box 10151, El Paso, Texas 79992		
Location of Well UNIT LETTER <u>I</u> <u>660</u> FEET FROM THE <u>East</u> LINE AND <u>1980</u> FEET FROM THE <u>South</u> LINE, SECTION <u>26</u> TOWNSHIP <u>18-S</u> RANGE <u>28-E</u> N.M.P.M.		

15. Elevation (Show whether DF, RT, GR, etc.)

3459.4 GL

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUS AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

FIELD OPERATIONS WILL BEGIN UPON YOUR APPROVAL.

Procedure

1. Run and set a CIBP at 2550' KB; pump 40 cement plug to spot.
2. Circulate hole with 9.5#/gal. salt water mud.
3. Run and set a CIBP at 1730' KB; pump 40 cement plug to spot. Spot plug 1680-1780'
4. Set a 250 foot cement plug from 650' to 400' KB.
5. Place a 10 sack plug with top at surface.
6. Cut-off well heads and instal a dry hole marker.
7. Clear, level and rip location.

Notify N.M.O.C.C. in sufficient time to be received.

*Plugging*

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

CHIEF James F. Brown TITLE CONSULTING ENGINEER DATE 10/28/91

PROVED BY [Signature] TITLE Field Rep DATE 11/12/91

CONDITIONS OF APPROVAL, IF ANY: