

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

N. OIL CONS COMMISSION

Drawer DD

Artesia, NM 88210

FORM APPROVED

Budget Bureau No. 1004-0135

Expires: March 31, 1993

5. Lease Designation and Serial No.

NM-02056

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

No. Turkey Track MU Fed

9. API Well No. Com #1

30-015-23136

10. Field and Pool, or Exploratory Area

Undesignated

11. County or Parish, State

Eddy Co., NM

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

DEC 17 1993

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

YATES PETROLEUM CORPORATION

(505) 748-1471

3. Address and Telephone No.

105 South 4th St., Artesia, NM 88210

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

660' FNL & 1980' FWL of Section 33-T18S-R29E (Unit C)

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

☒ Notice of Intent☒ Subsequent Report☐ Final Abandonment Notice

TYPE OF ACTION

☐ Abandonment☒ Recompletion☐ Plugging Back☐ Casing Repair☐ Altering Casing☐ Other Abandon Morrow; recomp.
in Strawn or Cisco☐ Change of Plans☐ New Construction☐ Non-Routine Fracturing☐ Water Shut-Off☐ Conversion to Injection☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Propose to abandon Morrow perforations 11021-11230' and recomplete higher to test Strawn interval 10242-10368'. If Strawn is nonproductive, will recomplete to Cisco 9781-9791' as follows:

1. POOH with tubing, packer and RBP.
2. Abandon Morrow perforations 11021-11230' by setting a CIBP at 10900' with 35' of cement on top of CIBP.
3. Perforate Strawn lime from 10242-10368' w/22 holes as follows: 10242, 43, 63, 64, 70, 71, 72, 10305, 06, 08, 20, 21, 22, 29, 30, 31, 66, 67 & 10368'.
4. RIH w/RBP and packer. Isolate and acidize perforations as follows: 10366-10368' with 500 gallons 15% HCL acid; 10305-10331' with 1000 gallons 15% HCL acid and ball sealers and 10242-10272' with 750 gallons 15% HCL acid and ball sealers.
5. Swab test entire interval 10242-10368'.
6. If Strawn is nonproductive, will abandon by setting a CIBP at 10200' with 35' of cement on top. Additional procedure to follow to recomplete to Cisco.

14. I hereby certify that the foregoing is true and correct

Signed

Title Production ClerkDate Dec. 2, 1993

(This space for Federal or State office use)

(ORIG. SGD.) JOE G. LARA

Approved by

Title Petroleum EngineerDate 12/14/93

Conditions of approval, if any: