

DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

N.M. Oil & Gas Division

Budget Bureau No. 1004-0135

811 S. 1st Street

Expires: March 31, 1993

Artesia, NM 88210-2834

License Designation and Serial No.

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.

Use "APPLICATION FOR PERMIT—" for such proposals

LC-028772-B

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

North Travis 12 Deep #1

9. API Well No.

30-015-23306

10. Field and Pool, or Exploratory Area

Travis Upper Penn

11. County or Parish, State

Eddy County, NM

SUBMIT IN TRIPLICATE

1. Type of Well ☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Harvey E. Yates Company

3. Address and Telephone No.

P.O. Box 1933, Roswell, NM 88202

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

O, 660' FSL & 1650' FEL

Sec 12, T18S, R28E

12 CHECK APPROPRIATE BOX (s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

☐

Notice of Intent

☒

Subsequent Report

☐

Final Abandonment Notice

TYPE OF ACTION

☐

Abandonment

☐

Recompletion

☐

Plugging Back

☐

Casing Repair

☐

Altering Casing

☒

Other Plug & Abandon

☐

Change of Plans

☐

New Construction

☐

Non-Routine Fracturing

☐

Water Shut-Off

☐

Conversion to Injection

☐

Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and log form)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If wells directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

PBTD: 10,845' (CIBP w/35' cement on top.)

TOC: 5 1/2" csg. TOC @ 7,640'.

PERFS: 9,834-9,872'.

SURFACE CASING: 13 3/8" set @ 355'.

INTERMEDIATE CASING: 8 5/8" set @ 2,900'.

- 1) Set CIBP @ 9,744' w/35' cement on top.
- 2) Cut and lay down approximately 7,500' of casing. Load hole w/9# mud.
- 3) Set 100' plug (50' in/50' outside of 5 1/2" casing stub). Tag plug.
- 4) Set 300' plug @ 4,500'. Tag plug.
- 5) Set 100' plug @ 2,950'. (50' in/50' outside of 8 5/8" casing shoe.)
- 6) Set 150' plug @ 355'.
- 7) Set 20 sxs cement surface plug.

14. I hereby certify that the foregoing is true and correct

Signed


Dianna Rodgers

Title Production Analyst

Date

22-Aug-00

(This space for Federal or State office use)

Approved by

Conditions of approval, if any:

Title

PETROLEUM ENGINEER

Date

