

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well <input checked="" type="checkbox"/> Oil Well <input type="checkbox"/> Gas Well <input type="checkbox"/> Other	5. Lease Designation and Serial No. LC-047633-B
2. Name of Operator Read & Stevens, Inc.	6. If Indian, Allottee or Tribe Name
3. Address and Telephone No. P. O. Box 1518 Roswell, New Mexico 88202 505/622-3770	7. If Unit or CA, Agreement Designation
4. Location of Well (Footage, Sec., T., R., M., or Survey Description) 1980' FNL & 990' FWL Section 1 T18S-R30E	8. Well Name and No. Susie Federal #1
	9. API Well No. 30-015-27677
	10. Field and Pool, or Exploratory Area Undesignated Bone Spring
	11. County or Parish, State Eddy County, New Mexico

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA		
TYPE OF SUBMISSION	TYPE OF ACTION	
<input checked="" type="checkbox"/> Notice of Intent	<input type="checkbox"/> Abandonment	<input type="checkbox"/> Change of Plans
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Recompletion	<input type="checkbox"/> New Construction
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Plugging Back	<input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Casing Repair	<input type="checkbox"/> Water Shut-Off
	<input type="checkbox"/> Altering Casing	<input type="checkbox"/> Conversion to Injection
	<input type="checkbox"/> Other Plug and Abandon	<input type="checkbox"/> Dispose Water
		(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Read & Stevens proposes to plug and abandon the well as follows:

- 1) Set a CIBP @ 6,830', dump 35' of cmt on top.
- 2) Circulate the hole w/ 9 ppg mud laden fluid.
- 3) Spot a 150' cmt plug across the 9 5/8" shoe from 4,180' to 4,030'.
- 4) Spot a 150' cmt plug at the top of the Yates from 1,300' to 1,350'.
- 5) Cut and pull the 5 1/2" csg at the free point, approx 800' from surface.
- 6) Lay down 5 1/2" csg, set 200' cmt plug at 5 1/2" csg stub to above the 13 3/8" shoe from 800' to 600'.
- 7) Cut off wellhead and set 50' surface plug, install dry hole marker and reclaim location.

Notify BLM prior to moving in, rigging up plugging crew.

14. I hereby certify that the foregoing is true and correct

Signed

John C. Wasey, Jr.

Title Petroleum Engineer

Date 2-23-96

(This space for Federal or State office use)

Original signed by Shannon J. Shaw

Title

PETROLEUM ENGINEER

Date

3/26/96

Approved by

Conditions of approval, if any:

RECEIVED

DEC 11 1965

U.S. DEPARTMENT OF AGRICULTURE
WASHINGTON, D.C.