

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

C15F  
Op

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

2040 Pacheco St.  
Santa Fe, NM 87505

WELL API NO. 30-015-30966
Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE
State Oil & Gas Lease No. E-3635
Lease Name or Unit Agreement Name SCOGGINS DRAW STATE "C" COM
Well No. 2
Pool name or Wildcat RED LAKE GLORIETA YESO

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL OTHER	RECEIVED OCD - ARTESIA
Name of Operator MARBOB ENERGY CORPORATION	Well No. 2
Address of Operator PO BOX 227, ARTESIA, NM 88210	Pool name or Wildcat RED LAKE GLORIETA YESO
Well Location Unit Letter B : 1020 Feet From The NORTH Line and 1950 Feet From The EAST Line Section 16 Township 18S Range 28E NMPM EDDT County	
Elevation (Show whether DF, RKB, RT, GR, etc.) 3464' GR	

11

Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK

PLUG AND ABANDON ☒

TEMPORARILY ABANDON

CHANGE PLANS

PULL OR ALTER CASING

OTHER:

SUBSEQUENT REPORT OF:

REMEDIAL WORK

ALTERING CASING

COMMENCE DRILLING OPNS.

PLUG AND ANBANDONMENT

CASING TEST AND CEMENT JOB

OTHER:

Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

PLUG AND ABANDON WELL AS FOLLOWS:

25 SX. Plug @ 3150'

1. SET CIBP @ 3300'. CIRCULATE THE WELL BORE FULL OF 9 PPG BRINE MIXED W/ 25 PPB OF SALT GEL. SPOT 10 SX CLASS "C" NEAT CMT (14.8 PPG, 1.32 CFPS, 6.3 GWPS) ON TOP OF CIBP.

2. PULL TBG TO 1920' & SPOT 25 SX CLASS "C" NEAT CMT CONT 2% CACL2 50' BELOW THE 8 5/8" CSG SHOE @ 1870'. TIH & TAG PLUG 2 HRS AFTER THE PLUG WAS SET. Perf. CSG @ 1920' 50' cmt outside CSG 1820-1920' Leave 100' cmt. inside CSG. 1820-1920' - TAG

3. CUT W/H & CSGS OFF 3' BELOW GROUND LEVEL & REMOVE. PICK UP 1" TBG, RIH DOWN 8 5/8" X 5.5" ANNULUS TO 60' & FILL W/ CLASS "C" NEAT CMT. RIH DOWN INSIDE OF 5.5" TO 60' & FILL W/ CLASS "C" NEAT CMT. SHOULD TAKE ABOUT 15 SX TO FILL UP F/ 60' TO SURF.

4. WELD PLATE ONTO 8 5/8" STUB. WELD A 4" DIAMETER DRY HOLE MARKER ONTO PLATE SUCH THAT 4' OF IT IS ABOVE GROUND LEVEL.

5. CUT OFF ANCHORS, PUCH IN & RECONTOUR PITS & CLEAN UP LOCATION.

Salt gel mud consisting of 10#  
Brine W/25# of gel per bbl  
must be placed between each plug

Notify OCD 24 hrs. prior to any work done

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

*Diana J. Cannon*

TITLE PRODUCTION ANALYST

DATE 11-23-01

TYPE OR PRINT NAME DIANA J. CANNON

TELEPHONE NO. 505-748-3303

(This space for State Use)

APPROVED BY

*[Signature]*

TITLE

*Wild Sep ID*

DATE 12-10-01

CONDITIONS OF APPROVAL, IF ANY: