

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

RECEIVED

JUN - 9 1992

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☒ Other

RE-ENTRY

2. Name of Operator

YATES PETROLEUM CORPORATION

(505) 748-1471

3. Address and Telephone No.

105 South 4th St., Artesia, NM 88210

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

Unit H, 1998' FNL & 660' FEL, Sec. 5-T20S-R24E

5. Lease Designation and Serial No.

NM 39635

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Mimosa AHS Federal #5

9. API Well No.

30-015-00055

10. Field and Pool, or Exploratory Area

Und. W. Dagger Draw Morrow

11. County or Parish, State

Eddy, NM

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☐ Notice of Intent
☒ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☒ Other Re-Entry

- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

5-22-92. Dug out celler for re-entry.

5-23-26-92. Dug down 10' with jack hammer. Brought 10-3/4" casing to surface and installed 10-3/4" X 3000# starting flange. Install cellar and leveled location. Washover marker and start re-entry. Pick up 5-3/4" OD shoe on 1 jt washpipe. Pick up 9-7/8" bit. Tag cement at 8'. Drill 2 minutes and lost circulation (hole in casing below splice). Weld patch over hole. Drill to 16' and lost circulation again (another hole in casing - cannot see). Drilling conventional. Continue in hole and tag at 789'. Drill to 792' (top of 8-5/8" casing. Can not get inside 8-5/8". POH. TIH w/9 1/2" lead block (appears 1/2 block went into stub. TIH w/ 6-1/8" bit. Work into stub and wash down 4 jts. Bit trying to plug on connections. POH w/ 6-1/8" bit and collars. TIH open-ended tubing w/mule shoe cut on first joint. Wash down to 1205'. Torquing - tubing stacks out. (Possible plug above San Andres perms @ 1305'.) No returns. Circulate clean and POH.

5-28-92. Verbal permission received from Shannon Shaw, BLM, Carlsbad, NM, to tie 8-5/8" casing together @ 792' and cement to surface as necessary. Permission obtained by Bill Hansen, YPC Consultant.

ACCEPTED FOR RECORD

Adm

JUN 11 1992

14. I hereby certify that the foregoing is true and correct

Signature *[Signature]*

Title Production Supervisor

(This space for Federal or State office use)

Approved by _____
Conditions of approval, if any:

Title _____

Date _____