

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

RECEIVED  
OIL CONSERVATION DIVISION  
P.O. Box 2088

Santa Fe, New Mexico 87504-2088  
APR 23 '89

WELL API NO.

5. Indicate Type of Lease

STATE ☒

FEE ☐

6. State Oil & Gas Lease No.

E-1051

7. Lease Name or Unit Agreement Name

Gulf State

8. Well No.

1

9. Pool name or Wildcat

Artesia-Queen-Grayburg-SA

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

OIL  
WELL ☒

GAS  
WELL ☐

OTHER P&A

2. Name of Operator

JOHN A. YATES, JR., - OPERATOR

3. Address of Operator

105 South 4th St., Artesia, NM 88210

4. Well Location

Unit Letter B : 330 Feet From The North Line and 2310 Feet From The East Line

Section 8 Township 19S Range 28E NMPM Eddy County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

PULL OR ALTER CASING ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103. Propose to plug well as follows:

- 1) GIH w/2-3/8" tubing to 2000' and spot 25 sx cement plug across perfs 1894-1947'.
- 2) Tag plug at 1844' or higher. 3) Perforate 4 squeeze holes at 1510'. Tie on to casing and establish circulation.\* 4) Set cement retainer at 1460' and circulate cement to surface.
- 5) POOH to 650' and spot 25 sx plug (250'). 6) Cut wellhead off 3' below ground level.
- 7) GIH w/tubing to 100' and spot cement plug to surface (10 sx).

\*If circulation cannot be established per 3, will use the following procedure.

- 4a) GIH w/tubing and spot 15 sx cement plug across 1510'.
- 5a) Perforate 4 squeeze holes at 500'.
- 6a) Tie on to casing and establish circulation to surface.
- 7a) Set retainer and cement w/125 sacks.
- 8a) Cut off wellhead.
- 9a) Spot 100 sx surface plug.
- 10a) Install marker.

NOTE: Hole will be loaded with NMOCD approved plugging fluid.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

*John A. Yates Jr.*  
JOHN A. YATES, JR.

TITLE Operator

DATE 4-26-89

TYPE OR PRINT NAME

TELEPHONE NO. 505/748-1471

(This space for State Use)

APPROVED BY

*Johnny Balunson*

TITLE

OIL AND GAS INSPECTOR

DATE

5-1-89

CONDITIONS OF APPROVAL, IF ANY:

Notify N.M.O.C.D. in sufficient time to witness.

DI