

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department.

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

RECEIVED

007 1 1 1993

WELL API NO.

30-015-0232

5. Indicate Type of Lease

STATE ☒

FEE ☐

6. State Oil & Gas Lease No.

State 648 Milman 7 Rivers East

7. Lease Name or Unit Agreement Name

State 648 Milman 7 Rivers East

8. Well No.

177

9. Pool name or Wildcat

Milman 7 Rivers EAST

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

OIL
WELL ☒

GAS
WELL ☐

OTHER

2. Name of Operator

DEKALB Energy Company % Steve Smith

3. Address of Operator

P.O. Box 10513, Bakersfield, CA 93389

4. Well Location

Unit Letter B : 330 Feet From The North Line and 2310 Feet From The East Line

Section 28 Township 19S Range 28E NMPM Eddy County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)
3391' GR

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

PULL OR ALTER CASING ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐

ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐

PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Remove tubing, if any, and clean out casing to 1114'. Cement across perforations, (1091'- 95, 1110'- 14') with 35 sacks "G". Tag cmt. top or set bridge plug above.
2. Perforate 4 1/2" casing at 757' and squeeze 25 sacks "G" cmt. from 700'.
3. Perforate 4 1/2" casing at 370' and squeeze 25 sacks "G" cmt. from 200'.
4. Mix 12 sacks "G" cmt. and fill 4 1/2" and 7" casing at surface.
5. Drilling mud will be placed between all cement plugs.
6. Cut off casing below ground level and install well marker.
7. Work to start as soon as rig available.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

Steve Smith

TITLE

Agent

DATE

9/25/93

TYPE OR PRINT NAME

Steve Smith

(805) 833-1032

TELEPHONE NO.

(This space for State Use)

APPROVED BY

Ray Smith

TITLE

OIL AND GAS DIVISION

DATE

007 1 1 1993

Cap CIBP
if used also need
cement behind 4 1/2
e surface shoe