

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

OIL CONSERVATION DIVISION

2040 South Pacheco
Santa Fe, New Mexico 87505

DISTRICT I

1625 N. French Drive, Hobbs, NM 88240

DISTRICT II

811 S. First Street, Artesia, NM 88210

DISTRICT III

1000 Rio Brazos Rd., Aztec, NM 87410

WELL API NO.

30-015- 03613

5. Indicate Type of Lease

STATE ☒ FEE ☐

6. State Oil & Gas Lease No.

VB-0158

7. Lease Name or Unit Agreement Name

Chaparral State

8. Well No.

#2

9. Pool Name or Wildcat

Und Winchester Bone Spring

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. Name of Operator

STRATA PRODUCTION COMPANY

3. Address of Operator

P.O. BOX 1030, ROSWELL, NEW MEXICO 88202-1030

4. Well Location

Unit Letter D : 660 Feet From The North Line and 660 Feet From The West Line

Section 32 Township 19 South Range 29 East NMPM Eddy County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

3309' GR

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work)
SEE RULE 1103

Strata Production Company resubmits its request that was originally submitted September 1, 1999 for approval to plug and abandon the well in the following manner: * Set 75 sack cement Plug @ 2125' TAG

1. Set retainer at 4970'. Squeeze with 75 sacks Class "C" cement with 35' of cement on top of plug. Perf. 7" to 5020'.
2. Set retainer at 3450'. Squeeze with 75 sacks Class "C" cement with 35' of cement on top of plug. Perf. 7" to 3550'.
3. Set 150' Plug half in half out of casing shoe at 3000'-2850' with 65 sacks Class "C" cement. Tag plug after 4 hours.
4. Set 100' Plug across Top of Salt at 1020'-920' with 45 sacks Class "C" cement. Tag plug after 4 hours.
5. Set 100' Plug half in half out of casing shoe at 428'-328' with 45 sacks Class "C" cement. Tag plug after 4 hours.
6. Set Surface Plug with 10 sacks Class "C" cement.
7. Spot gelled brine water between each plug. Cut off and install Dry Hole Marker. Clean location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Carol J. Garcia TITLE PRODUCTION RECORDS MANAGER DATE 6/26/00
TYPE OR PRINT NAME CAROL J. GARCIA TELEPHONE NO 505-622-1127

(This space for State Use)

APPROVED BY Michael Stuebel TITLE Field Rep. II DATE 6/29/2000
CONDITIONS OF APPROVAL, IF ANY:

* Notified N.M.O.C.D. to witness Plugging Operations.