

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

P.O. Box 2088
Santa Fe, New Mexico 87504-2088

RECEIVED

JUL 29 1991

WELL API NO.
30-015-05667

5. Indicate Type of Lease
STATE ☒ FEE ☐

6. State Oil & Gas Lease No.
E-10001

SUNDRY NOTICES AND REPORTS ON WELLS O. C. D.
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG OR ABANDON A WELL IN A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

7. Lease Name or Unit Agreement Name

New Mexico "Y" State

1. Type of Well:
OIL WELL ☐ GAS WELL ☐ OTHER Water Injection

2. Name of Operator
Southland Royalty Company

8. Well No.
1

3. Address of Operator
P.O. Box 51810, Midland, TX 79710-1810

9. Pool name or Wildcat
Shugard (Y,SR,Q,G)

4. Well Location
Unit Letter G : 1650 Feet From The North Line and 2310 Feet From The East Line
Section 32 Township 18-S Range 31-E NMPM Eddy County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)
3580' DF

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plug and Abandon

RIH w/bull plugged PC tbq and pressure test to find possible leaks. Discard bad joints.

SHORT STRING: Set pkr at 2400'. Pressure up on annuylus to test for casing leaks. Pump fresh wtr to establish inectability. Pump 100 sx of Class C cement w/4% CaCl2 down 2-7/8", 6.4 # csg. WOC. Tag TOC. If TOC is below 10' from surface, use Class C cement and circulate to surface.

LONG STRING: Set CIBP at 3430'. Presure test casing for leaks. Cap CIBP w/2 sx of Class C cmt. Load hole with 10 ppg gelled mud. Perf 4 spf at 1550'-51' (8 holes). Pump 450 sx of Class C cement w/2% CaCl 2 and circulate to surface. WOC. Tag cement top. Cut csg 3' below surface and weld on steel plate. Set abandonment maker. Retore Location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Maria L. Perez TITLE Production Asst. DATE 7-25-91

TYPE OR PRINT NAME Maria L. Perez TELEPHONE NO. 915-686-5767

(This space for State Use)

APPROVED BY Gleny Robinson TITLE OIL AND GAS INSPECTOR DATE 7-30-91

CONDITIONS OF APPROVAL, IF ANY: