

Operator SWR Operating Co. -  
 Well Donokey, American #1  
 Unit G Section 5 Township 19 Range 31  
 API # 30-015-05739

TOPS

T. Salt 901  
 B. Salt 2183  
 Yates 2365  
 Glorieta \_\_\_\_\_  
 Delaware \_\_\_\_\_  
 Bone Sp. \_\_\_\_\_  
 Abo \_\_\_\_\_  
 Wolfcamp \_\_\_\_\_  
 Morrow \_\_\_\_\_  
 Devonian \_\_\_\_\_  
 Fusselman \_\_\_\_\_  
 Other Queen 3245

← Perfcs. @ 60' - Circ cnt 0-60'

← Place 100' of cnt inside & outside of  
 CS9 160'-260' - TAG

← Perfcs @ 260'

← Place 100' of cnt 800'-900' - inside &  
 outside of CS9. TAG

← Perf CS @ 900'

← Place 100' of cnt inside & outside  
 of CS9 2200-2300 - TAG

← Perf CS @ 2300'

2900 — TOC @ 50%

← 2.5 SX plug @ 3100' - TAG

3400 — CTBP 5-85 - Perf Queen Zone 5-85  
 3484 — Perfs  
 3513

4 1/2 3340

150 SX  
 7 1/2 hole

- Contact OCD 24 hrs. prior to any work done
- Salt gel mud consisting of 10# brine with 2% of gel per barrel must be placed between each plug
- Install dry hole marker as per rule 202.B.2
- Plugs are to be set from point indicated up. Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- Surface plug will be from 0' - 60'
- Where plugs are required cement must be placed inside and outside of all casing string(s), in the correct footage or sacks required, if no cement exists.
- Plugs to be tagged will be indicated.