

Form 9-331  
(May 1963)UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEYSUBMIT IN TRIPL. (E)  
(Other instructions on re-  
verse side)Form approved.  
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Greenwood Unit

9. WELL NO.

9

10. FIELD AND POOL, OR WILDCAT

Shugart

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

Sec. 27

T-18-S, R-31-E

12. COUNTY OR PARISH

Eddy

13. STATE

N.M.

1. OIL WELL ☐ GAS WELL ☐ OTHER ☒ Dry Hole

OCT 3 1979

2. NAME OF OPERATOR

Southland Royalty Company

3. ADDRESS OF OPERATOR

1100 Wall Towers West, Midland, Texas 79701

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*  
See also space 17 below.)  
At surfaceUnit Letter L, 2310' FSL, 660' FWL, Sec. 27,  
T-18-S, R-31-E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3629' GR

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

## NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON\* ☐CHANGE PLANS ☐(Other) Re-enter & replug ☒

## SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT\* ☐(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

To re-enter &amp; replug the former Pan Am Petr. Greenwood Unit #9. This re-entry was requested during a meeting with the NMOCC &amp; USGS on 4-19-79.

1. Rig up and drill out plugs @ surface, 8 5/8" csg shoe and 1900' (See attached schematic).
2. Tag plug @ 3800'. If plug in place go to step 3. If not set 100' plug from 3700-3800'.
3. Spot 100' plug from 3300-3400' to isolate Penrose.
4. Spot 200' plug @ base of salt 2250-2450' (tag plug).
5. Spot 100' across 8 5/8" csg shoe @ 629'.
6. Spot 10 sx. surface plug.

Class 2 w/2-7-9

10-24-79 Set Bottom Plug 3867 to 3617 Tagged @ 3617  
 10-25-79 Set 80 SX @ 3410 Tagged @ 3250  
 10-26-79 Set 200 SX @ 2444 Tagged @ 1435  
 Set 100 SX 2%cc @ 651 Tagged to 396  
 Set 10 SX @ Surface

18. I hereby certify that the foregoing is true and correct

SIGNED

C. Harvey Carr

TITLE

District Engineer

DATE

10-2-79

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY: