

Form 9-331
(May 1963)UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE
(Other instructions on reverse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC-029392-B

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)1. OIL WELL ☐ GAS WELL ☐ OTHER ☒ Dry Hole OCT 10 1979

2. NAME OF OPERATOR

Southland Royalty Company

O.C.C.

ARTESIA, OFFICE

3. ADDRESS OF OPERATOR

1100 Wall Towers West, Midland, Texas 79701

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*

See also space 17 below.)
At surfaceUnit Letter L, 2310' FSL, 660' FWL, Sec. 27,
T-18-S, R-31-E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3629' GR

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Greenwood Unit

9. WELL NO.

9

10. FIELD AND POOL, OR WILDCAT

Shugart

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 27

T-18-S, R-31-E

12. COUNTY OR PARISH

13. STATE

Eddy

N.M.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) Re-enter & replug ☒PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☐CHANGE PLANS ☐

xx

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐(Note: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

To re-enter & replug the former Pan Am Petr. Greenwood Unit #9. This re-entry was requested during a meeting with the NMOCC & USGS on 4-19-79.

1. Rig up and drill out plugs @ surface, 8 5/8" csg shoe and 1900' (See attached schematic).
2. Tag plug @ 3800'. If plug in place go to step 3. If not set 100' plug from 3700-3800'.
3. Spot 100' plug from 3300-3400' to isolate Penrose.
4. Spot 200' plug @ base of salt 2250-2450' (tag plug).
5. Spot 100' across 8 5/8" csg shoe @ 629'.
6. Spot 10 sx. surface plug.

RECEIVED

OCT 5 1979

U.S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

C. Harvey Carr

TITLE District Engineer

DATE 10-2-79

(This space for Federal or State office use)

(Orig. Sgd.) GEORGE H. STEWART

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

ACTING DISTRICT ENGINEER

TITLE

DATE OCT 9 1979