

UNITED STATES DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

NM OIL & GAS
SUBMIT IN TRIPPLICATE
(Other instructions on re-verse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC-029387C

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Kenwood

9. WELL NO.

2

10. FIELD AND POOL, OR WILDCAT

Shugart (Y, 7R, Q, GB)

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 29, T-18-S, R-31-E

12. COUNTY OR PARISH

Eddy

13. STATE

N.M.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

APR 13 1982

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Southland Royalty Company

3. ADDRESS OF OPERATOR

1100 Wall Towers West, Midland, Texas 79701

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface

990' FNL & 330' FWL, Sec. 29, T-18-S, R-31-E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

Unknown

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

☐
☐
☐
☐
☒

PULL OR ALTER CASING

☐
☐
☐
☐
☐

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

☐
☐
☐

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

☐
☐
☐
☐
☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) *

Repair casing leak as follows:

1. MIRU CU. POOH w/rods. Tag PBTD. POOH w/tbg. Install BOP.
2. RIH w/CIBP on WL & set @ 3305'.
3. RIH w/2 7/8" WS & pkr. Locate top & bottom holes in csg. POOH.
4. RIH w/cmt retainer on WL & set 30' above top hole. RIH w/WS & sting into retainer. Establish inj rate & check for circulation into annulus. Notify Midland if have circ.
5. Squeeze leak w/300 sx Class "C" cmt containing 1/4#/sk flocele, 5# sand/sk & 4% Cacl. Sting out & reverse tbg clean. POOH. WOC.
6. RIH w/4 3/4" bit & DC on WS. Drill out retainer & cmt. Tst csg to 1000 psi. Drill out CIBP & clean out to 3838'. POOH.
7. RIH w/rods & tbg as before. Place well on test.

RECEIVED
APR 7 1982

OIL & GAS
U.S. GEOLOGICAL SURVEY
ROSWELL, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

Trey R. ...

TITLE District Operations Engineer

DATE 4-5-82

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

APPROVED

DATE

APR 9 1982

JAMES A. GILLHAM
DISTRICT SUPERVISOR

*See Instructions on Reverse Side