

N.M. Oil Co. Division
611 S. 1st Street
Alameda, NM 88210-2834

Form 3160-5
(June 1990)

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

5. Lease Designation and Serial No.

NM 94845

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Duncan Federal #1

9. API Well No.

30-015-10375

10. Field and Pool, or Exploratory Area

West Lusk Delaware

11. County or Parish, State

Eddy, New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

RECEIVED

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Lynx Petroleum Consultants, Inc.

APR 10 1997

3. Address and Telephone No

P.O. Box 1979, Hobbs, NM 88241

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

760' FNL & 990' FEL

Sec. 27, T-19S, R-31E.

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

☒ Notice of Intent

☐ Subsequent Report

☐ Final Abandonment Notice

TYPE OF ACTION

☒ Abandonment

☐ Recompletion

☐ Plugging Back

☐ Casing Repair

☐ Altering Casing

☐ Other

☐ Change of Plans

☐ New Construction

☐ Non-Routine Fracturing

☐ Water Shut-Off

☐ Conversion to Injection

☐ Dispose Water

(Note: Rep. results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

1. Circulate hole with brine mud.
2. Spot 5 sxs cement on top of C.I.B.P. at 6825'.
3. Cut and pull 4 1/2" casing at 4050'.
4. Spot a 60 sxs cement casing stub and casing shoe plug 3895-4100' (tag plug).
5. Perforate the 8 5/8" casing at 750'. Circulate 300 sxs cement and leave 100' cement inside casing.
6. Spot 15 sxs cement surface plug.
7. Cut off wellheads and anchors. Install dryhole marker.

APR 14 1997

ROSWELL, NM

14. I hereby certify that the foregoing is true and correct

Signed

Max Wain

Title President

Date 4/3/97

(This space for Federal or State office use)

Approved by (ORIG. SGD.) DAVID R. GLASS
Conditions of approval, if any.

Title PETROLEUM ENGINEER

Date APR 08 1997

SEE ATTACHED FOR
CONDITIONS OF APPROVAL