

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY
N. M. O. C.
SUBMIT IN TWO COPIES
(Other instructions on reverse side)Form approved.
Budget Bureau No. 42-R1424

5. LEASE DESIGNATION AND SERIAL NO.

NM 02447

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

Big Eddy Unit

8. FARM OR LEASE NAME

Big Eddy Unit

9. WELL NO.

5

10. FIELD AND POOL, OR WILDCAT

Lusk (Strawn)

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 34, T19S, R31E

12. COUNTY OR PARISH 13. STATE

Eddy

N. Mex.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)1. OIL WELL ☒ GAS WELL ☐ OTHER

2. NAME OF OPERATOR

Perry R. Bass

3. ADDRESS OF OPERATOR

Box 1178, Monahans, Texas 79756

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

1980' FWL and 660' FNL, Unit letter C.

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3486' RDB

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Abandonment operations are expected to begin on or about June 24, 1969.

Procedure: Pull rods & tubing - rerun tubing with cement retainer; set @ 11,375' and cement perforations 11,438' - 11,424' with 50 sks reg. cement. Pick up out of retainer & displace hole with 9.0 to 9.2 PPG brine gel mud - pull tubing. Determine free point (est. @ 9,700', top of cement) of 4 1/2" OD casing. Cut 4 1/2" casing at assumed free point of 9,700' - spot 60 sks cement through 4 1/2" casing (est. top of plug 9,537') - pull casing to 8,200' and spot 60 sks cement through 4 1/2" casing (est. top of 8,037') - pull casing to 6,700' and spot 60 sks cement through 4 1/2" casing (est. top of plug 6,537') - pull casing to 3,985' and spot 45 sks cement through 4 1/2" casing (est. top of plug 3,842'). Complete pulling 4 1/2" casing. Locate free point of 8 5/8" casing (est to be @ 700'). Cut 8 5/8" casing and pull out of hole. Run tubing to 50' below 8 5/8" cut off point - spot 75 sks cement (est. 102' plug). Pull tubing - spot 38 sks cement @ 50' below ground level in the 13 3/8" OD surface casing. Install required 4" OD stenciled well marker extending 4' above mean ground level. Clean location for final inspection.

JUN 7 1969

RECEIVED
MAY 29 1969

Note: All intervals between cement plugs will be mud-filled.

U. S. GEOLOGICAL SURVEY
ARTES

18. I hereby certify that the foregoing is true and correct

SIGNED

Jack L. BEEKMA

TITLE Division Engineer

DATE May 28, 1969

(This space for Federal or State office use)

APPROVED

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

V2 -
R. L. BEEKMA

*See Instructions on Reverse Side