

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPlicate  
(Other Instructions on Reverse Side)

Budget Bureau No. 1004-0135  
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.

NM-0557148

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Sweeney Federal

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Lusk (Strawn)

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

Sec. 14, T19S, R31E

12. COUNTY OR PARISH 13. STATE

Eddy

NM

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

RECEIVED

OIL WELL ☐ GAS WELL ☒ OTHER

2. NAME OF OPERATOR

Damson Oil Corporation

3. ADDRESS OF OPERATOR

3300 N. A, Bldg. 8, Ste. 100, Midland, Texas 79705

1. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.)

See also space 17 below

At surface

Unit G, 1980' FNL & 1980' FEL

Sec. 14, T19S, R31E

14. PERMIT NO.

N/A

15. ELEVATIONS (Show whether DT, RT, CA, etc.)

3535.4' GR

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

☐  
☐  
☐  
☐  
☐

PULL OR ALTER CASING

☐  
☐  
☐  
☐  
☐

FRACTURE TREAT

MULTIPLE COMPLETION

SHOOT OR ACIDIZE

ABANDON\*

REPAIR WELL

CHANGE PLANE

(Other) Re-complete in Lower Zone

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

☐  
☐  
☐

REPAIRING WELL

☐  
☐  
☐

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT\*

(Other)

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Plan to re-complete in Lower Strawn Zone as follows:

- 1) RU. Kill well w/2% KCL & pull tubing.
- 2) GIH w/workstring, mill and washover pipe. Cut over BP at 11,250'. Retrieve fish if possible, otherwise push fish below 11,340'.
- 3) RIH w/RBP and packer. Set RBP at 11,320' and packer at 11,280'. Acidize lower perforation with 2000 gals 15% NE Acid.
- 4) Retrieve RBP and set at 11,240'. Set packer at 11,180' and acidize upper perforations with 2000 gals 15% NE acid.
- 5) Pull RBP and packer and run production tubing. Rig up swab and swab test well to determine productivity.

RECEIVED  
NOV 1 10 52 AM '88  
CARRIZO  
AREA

18. I hereby certify that the foregoing is true and correct

SIGNED

D. R. Craig

TITLE District Engineer

DATE 10/31/88

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

\*See Instructions on Reverse Side