

7. Drill 7-7/8" hole to a total depth of 9800' using water to drill to 7000', use 2% KCl brine to 9200', mud up with polymer starch mud w/3.7#/gal., Wt. 45, Sec. viscosity, 10 cc water loss. At 9200' increase viscosity as necessary to maintain hole.
8. Drill stem test all shows.
9. Run logs (Combination GNL - FDC w/Gamma Ray, DDL, and Dip Meter).
10. Set and cement 4-1/2" oil string (resin coated and centralized through pay zone) with 450 sxs. Incorporate cement with 7.6# salt and 1% Halad-9. Pump plug down with 2% KCl packer fluid. Run temperature survey to locate cement top.

RECEIVED
JUN - 6 1974
U. S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO