

N.M.O.C.D. COPY
UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPL
(Other instructions on
reverse side)Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER		5. LEASE DESIGNATION AND SERIAL NO. NM 08386
2. NAME OF OPERATOR Monsanto Company		6. IF INDIAN, ALLOTTEE OR TRIBE NAME
3. ADDRESS OF OPERATOR 1330 Midland National Bank Midland, Texas 79701		7. UNIT AGREEMENT NAME
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 1980' FWL & 1980' FSL		8. FARM OR LEASE NAME Dagger Draw
14. PERMIT NO.		9. WELL NO. 2
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3513 GR		10. FIELD AND POOL, OR WILDCAT Cemetery - Morrow
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec 8, T-20S, R-25E
		12. COUNTY OR PARISH Eddy
		13. STATE N. M.

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETION

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT*

(Other)

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Work estimated to begin February, 1981.

- 1) Set CIBP @ 5950' in 5 1/2" casing. Cap CIBP with 20' cement.
- 2) Determine free point. Pull 5 1/2" casing where free (Approx. 5500').
- 3) Run in hole with tubing and circulate hole with 9.5 ppg brine.
- 4) Spot 5 1/2" casing stub plug 75' in and 75' above 5 1/2" cut.
- 5) Spot 150' plug at top of Bone Springs at 4214'.
- 6) Spot 150' plug at top of Glorieta at 2228'.
- 7) Set cement retainer in 9 5/8" at 1200' (shoe at 1272') and squeeze with 50 sx. Pull up and dump 10 sx on top of retainer.
- 8) Set 15 sx plug at surface. Weld on marker.
The USGS will be contacted prior to any deviations from above procedure.

RECEIVED
FEB 05 1981
O. C. D.
ARTESIA, NEW MEXRECEIVED
JAN 30 1981U. S. GEOLOGICAL SURVEY
BOSWELL, NEW MEX

18. I hereby certify that the foregoing is true and correct

SIGNED P. W. Chester DEBTITLE Regional Production Mgr.DATE 1/29/81

(This space for Federal or State office use)

APPROVED BY (Orig. Sgd.) PETER W. CHESTERTITLE ACTING DISTRICT ENGINEERDATE FEB 2 1981

CONDITIONS OF APPROVAL, IF ANY: