

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION
RECEIVED

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

APR 29 1982

clms

O. C. D.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A NEW OR EXISTING RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- 2. Name of Operator Mewborne Oil Company 3. Address of Operator P. O. Box 7698 Tyler, Texas 75701 4. Location of Well UNIT LETTER J 2130 FEET FROM THE South LINE AND 1980 FEET FROM THE East LINE, SECTION 21 TOWNSHIP 20S RANGE 24 E N.M.P.M. 15. Elevation (Show whether DF, RT, GR, etc.) 3730 GR		5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/> 5. State Oil & Gas Lease No. 7. Unit Agreement Name 8. Farm or Lease Name Foster 9. Well No. 1 10. Field and Pool, or Wildcat Foster Ranch - Morrow 12. County Eddy
--	--	--

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. 4-16-82 Set C.I.B.P. 8800
2. 4-17-82 25 sack plug at 8,800' to cap C.I.B.P.
3. Mixed mud and circulated casing.
4. 4-20-82 35 sack plug at 5,520'. 50 in and 50 out of sub.
5. 4-20-82 Tagged top of plug at 5374'
6. 4-21-82 35 sack plug at 4841'.
7. 4-21-82 35 sack plug at 3696'.
8. 4-21-82 35 sack plug at 2004'.
9. 4-21-82 35 sack at 1295'. 50' below 8 5/8 shoe. Tagged plug at 1,110'.
10. 4-22-82 35 sack at 370'.
11. Cut off well head and place a 10 sack surface plug and dry hole marker.

*Post ID-2
5-21-82
P+H*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Delora Heard TITLE Production Clerk DATE 4-26-82

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: