

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

NM OIL CONS. COMMISSION
DRAWER DD
ARTESIA, NM 88210

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

RECEIVED

AUG 23 1993

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

McKay Oil Corporation

3. Address and Telephone No.

Post Office Box 2014, Roswell, NM

623-4735

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1980' FWL & 660' FNL

Sec. 25-20S-24E

5. Lease Designation and Serial No.

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Charolette McKay #3

9. API Well No.

30-015-21561

10. Field and Pool, or Exploratory Area

Dagger Draw South

11. County or Parish, State

Eddy, New Mexico

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment
☒ Recompletion Wolfcamp Formation
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Operator plans to recomplete the lower Wolfcamp Formation as follows:

1. Set cast iron bridge plug @ approximately 7,650' to seal off the Canyon formation. Cover bridge plug w/approximately 35 feet of cmt.
2. Load hole w/50% brine water and perforate the lower Wolfcamp.
3. Set Packer above the perforations and acidize w/2000 gals. of 15% acid. Swab and flow well to cleanup.
4. Run Bottom Hole Bomb, shut-in until tbq press. stabilizes. Flow test the well for 8 hours. SI well until tbq press. stabilizes. Pull bottom hole press. bomb.

RECOMPLETION OF UPPER WOLFCAMP FORMATION

1. Kill well w/50% brine water. RU and perforate upper Wolfcamp. RIH w/Pkr & BP.
2. Acidize w/3000 galls of 15% acid. Swab & flow to cleanup.
3. Run BHP bomb. SI untill tbq. press. stabilizes. Flow well for 8 hr test. SI until tbq. press. stabilizes. Pull BHP bomb.
4. Kill well w/50% brine. Pull out of hole w/pkr & BP. Run in hole w/Pkr., set above upper Wolfcamp perforations. Swab & flow to clean-up.

14. I hereby certify that the foregoing is true and correct

Signed Theresa Rodriguez
(This space for Federal or State office use)

Title Production Analyst

Date 7-14-93

Approved by _____
Conditions of approval, if any:

Title Patricia M. Santiago

Date 8-17-93