

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	<input checked="" type="checkbox"/>
FILE	<input checked="" type="checkbox"/>
U.S.O.S.	
LAND OFFICE	
OPERATION	<input checked="" type="checkbox"/>

OIL CONSERVATION DIVISION
RECEIVED BY O. BOX 2088
SANTA FE, NEW MEXICO 87501
FEB 07 1986
O. C. D.
ARTESIA, OFFICE

Form C-103
Revised 10-

5a. Indicate Type of Lease
State ☐ Fee ☒
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE APPLICATION FOR PERMIT TO DRILL (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name ---
2. Name of Operator PENROC OIL CORPORATION	8. Farm or Lease Name Angell Ranch Co
3. Address of Operator P O DRAWER 831, MIDLAND TX 79702	9. Well No. 1
4. Location of Well UNIT LETTER B 1980 FEET FROM THE East LINE AND 660 FEET FROM THE North LINE, SECTION 33 TOWNSHIP 19S RANGE 23E N.M.P.M.	10. Field and Pool, or Wildcat Winchester Morr
15. Elevation (Show whether DF, RT, GR, etc.) 3340 GR	12. County Eddy

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1-21-86 Set CIBP at 8800'. Mix mud and displace hole with mud mix and spot 50' cement plug above CIBP. Pull up & spot 25 sk. cement plug at 7825'-7725'.
- 1-22-86 Perforate 4½" csg. at 4100'. Set cement retainer at 4050'. Pump 50 sxs cement thru csg. perfs at 4100'. Perforate 4½" csg. at 2750'. Set cement retainer at 2700'. Pump 50 sxs. cement thru csg. perfs at 2750'. Perforate 4½" csg. at 400'. Circulate cement thru perfs at 400' with 115 sks. cement. Cut off well head.
- 1-24-86 Set dry hole marker. Removing surface equipment. Will fill pits and clean location. Will notify when ready for inspection for final approval.

Post ID-2
2-21-86
PFA

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Z. J. Dally</u>	TITLE <u>President</u>	DATE <u>2-6-86</u>
APPROVED BY <u>Danell Moore</u>	TITLE <u>Geologist</u>	DATE <u>3/11/86</u>
CONDITIONS OF APPROVAL, IF ANY:		