

Submit 3 Copies  
to Appropriate  
District Office


State of New Mexico  
Energy, Minerals and Natural Resources Department

58  
Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410



OIL CONSERVATION DIVISION

2040 Pacheco St.  
Santa Fe, NM 87505

WELL API NO. 30 015 22186
Indicate Type of Lease STATE FEE <input checked="" type="checkbox"/>
State Oil & Gas Lease No.
Lease Name or Unit Agreement Name <del>Graham Mayer</del> <b>Graham Mayer 24</b>
Well No. 1
Pool name or Wildcat Morrow

<b>SUNDRY NOTICES AND REPORTS ON WELLS</b> (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL OTHER	
Name of Operator Nearburg Producing Company	
Address of Operator 3300 North "A" Street, Building 2, Ste 120, Midland, TX 79705	
Well Location Unit Letter C 660 Feet From The north Line and 1980 Feet From The west Line Section 24 Township 20S Range 24E NMPM Eddy County	
Elevation (Show whether DF, RKB, RT, GR, etc.) 3616' GR	

11

Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐  
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ANBANDONMENT ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER: ☐

<sup>12</sup>Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103

Nearburg Producing Company requests to Plug and Abandon the above referenced well.

1. Set CIBP @ 9300', cap w/ 35' cmt.
2. Set CIBP @ 8730', cap w/ 35' cmt
3. Set 100' plug 5605-5850'. (Top of Wolfcamp 5809'). **25 sk plug 5605-5850'**
4. Cut 5-1/2" csg @ 4000' and pull. Set 100' stub plug 50 in & 50 out of stub. Tag.
5. Set 100' plug f/ 2150' to 2200'. (Top of Glorinda - 2170') **2070-2170**
6. Set 100' plug f/ 1350' to 1450'. (Base 9-5/8" shoe @ 1400') **100' plug - 3700-3800'**
7. Set 100' plug 365' to 465' (Base surface csg - 415') - **TAG**
8. Set 30' surface plug. **60'**
9. Install dry hole marker.

**Salt gel mud consisting of 10#  
Brine W/25# of gel per bbl  
must be placed between each plug**

**Notify OCD 24 hrs. prior to any work done**

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE *Kim Stewart*

TITLE Regulatory Analyst

DATE 02-18-2002

TYPE OR PRINT NAME Kim Stewart

TELEPHONE NO. 915-686-8235

(This space for State Use)

APPROVED BY

*[Signature]*

TITLE

*[Signature]*

DATE

**FEB 22 2002**

CONDITIONS OF APPROVAL, IF ANY: