

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

Cons.
N.M. DIV-Dist. 2
1301 W. Grand Avenue
Artesia, NM 88210

APPROVED
Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well <input type="checkbox"/> Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other	5. Lease Designation and Serial No. NM 30062
2. Name of Operator PRONGHORN MGT. CORP. /	6. If Indian, Allottee or Tribe Name
3. Address and Telephone No. P.O. BOX 1772 HOBBS, NM 88241 505-393-9176	7. If Unit or CA, Agreement Designation
4. Location of Well (Footage, Sec., T., R., M., or Survey Description) 1980' FNL & 660' FEL S30-T20S-R24E	8. Well Name and No. Long Box #1
	9. API Well No. 30-015-22624
	10. Field and Pool, or Exploratory Area Tres Hombres Atoka
	11. County or Parish, State Eddy

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION
<input checked="" type="checkbox"/> Notice of Intent	<input type="checkbox"/> Abandonment
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Recompletion
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Plugging Back
	<input type="checkbox"/> Casing Repair
	<input type="checkbox"/> Altering Casing
	<input type="checkbox"/> Other
	<input checked="" type="checkbox"/> Change of Plans
	<input type="checkbox"/> New Construction
	<input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Water Shut-Off
	<input type="checkbox"/> Conversion to Injection
	<input type="checkbox"/> Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Move in and Rig up. Install B.O.P.
 2. POOH with tubing and packer. Tag CIBP and cement @ 8385'
 3. Set C.I.B.P. @ ±8000'. Cap with 35' cement. - Tag
 4. Perforate Cisco Canyon
 5. Swab test well. Treat as necessary
 6. Put well on production. Test for commercial production.
 7. If not productive, prepare to P&A well. Circulate hole w/mud laden fluid.
 8. Nipple up to 4 1/2" casing. Stretch, cut and pull casing.
 9. Spot 100' cement plug. 50' in and 50' out of 4 1/2" stub ±5000'. - Tag
 10. Set 100' cement plug 2763' - 2863'.
 11. Set 100' plug @ 8 5/8" shoe. 50' in and 50' out 1875' - 1975'. - Tag
 12. Set 100' plug @ 13 3/8" shoe. 50' in and 50' out. 345' - 445'. - Tag
 13. Set 50' surface plug. Erect dry hole marker.
 14. Clean location. Move out equipment.
- *Mud laden fluid to be circulated with all plugs.

Accepted for record - NMOCD

14. I hereby certify that the foregoing is true and correct

Signed [Signature] Title Partner Date 5-6-02

(This space for Federal or State office use)

Approved by **DENIED** Title (ORIG. SGD.) GARY GOURLEY Date 5/10/02